MAX20094/MAX20095

Backup Battery Charger and Boost Controller

General Description

The MAX20094/MAX20095 ICs combine a configurable constant-current/constant-voltage (CC/CV) battery charger with a high-efficiency synchronous boost controller to supply critical systems in the event the primary power source is lost. In addition, diagnostic features are available to check battery state-of-health (SOH) and IC functionality. Charging thresholds and the boost output voltage are configurable to support popular battery chemistries and a wide range of cell counts. To support system integration, the ICs have an I²C slave port through which configuration and status bits can be accessed.

Switching frequency of 2.2MHz also helps to reduce system cost by minimizing inductor size. The ICs also include a precision battery SOH check and have built-in functionality to minimize leakage current out of the back-up battery (BUB).

The MAX20094/MAX20095 are available in a 28-pin (5mm x 5mm) side-wettable TQFN package and are AECQ-100 qualified.

Applications

- Automotive Telematics Battery Backup
- Single or Multicell Battery-Backup Systems


Benefits and Features

- Efficient Solution
 - Minimum 2V Sync Boost with n-Channel FET Control
 - Skip Mode Guarantees > 50% Efficiency at 1mA
- Multiple Functions to Enable Small Solution Size
 - · 3V to 6V CC/CV Battery Charger
 - I²C-Settable Charging Current Up to 1A
 - I²C-Selectable CV Voltage and CC Current Levels
 - · Gate-Driver Output for p-Channel Load Disconnect
 - · Backup Battery Switchover-Trigger Signal
- State-of-Health for Backup Battery Monitoring
 - I²C Interface Diagnostics and Control Interface
 - Accurate Internal Current Sink for Battery Impedance Measurement
 - Analog Readout of Internal Sink Current from Backup Battery
 - Remote Sense for BATT_ Voltage Measurement
- Robust for Automotive Environment
 - 3.5V to 36V V_{IN} (40V Load-Dump Tolerant)
 - < 1µA Leakage for Pins Connected to the Battery
 - -40°C to +125°C Operating Temperature Range
 - 28-Pin, Side-Wettable TQFN Package Enables Optical Inspection

Ordering Information appears at end of data sheet.



Simplified Block Diagram



Backup Battery Charger and Boost Controller

Absolute Maximum Ratings

SUP2, DH, LX, SG1, CSP, CSN to PGND0.3V to +40V	BATTP, SNK, BATTS, SUP1 to AGND0.3V to +7.0V
G1 to SG17.0V to +0.3V	AVB to AGND0.3V to V _{BATTS} + 0.3V
BST to LX0.3V to +6V	G2 to BATTP6.0V to +0.3V
CSP to CSN0.3V to +0.3V	Operating Temperature Range40°C to +125°C
AVI, BUBTRIG, DL, COMP,	Junction Temperature+150°C
IMON to AGND0.3V to V _{BIAS} + 0.3V	Storage Temperature Range40°C to +150°C
SCL, SDA to AGND0.3V to V _{DDIO} + 0.3V	Soldering Temperature (reflow)+260°C
PGND to AGND0.3V to +0.3V	ESD Protection - Human Body Model±2kV
EN1B, BIAS, VDDIO, STATUSB to AGND0.3V to +6V	

Stresses beyond those listed under "Absolute Maximum Ratings" may cause permanent damage to the device. These are stress ratings only, and functional operation of the device at these or any other conditions beyond those indicated in the operational sections of the specifications is not implied. Exposure to absolute maximum rating conditions for extended periods may affect device reliability.

Package Information

28-Pin (5mm x 5mm x 0.75mm) Side-Wettable TQFN

PACKAGE CODE	T2855Y+5C
Outline Number	21-100130
Land Pattern Number	90-0027
Thermal Resistance, Single-Layer Board:	
Junction to Ambient (θ _{JA})	48°C/W
Junction to Case (θ _{JC})	3°C/W
Thermal Resistance, Four-Layer Board:	
Junction to Ambient (θ _{JA})	35°C/W
Junction to Case (θ _{JC})	3°C/W

For the latest package outline information and land patterns (footprints), go to www.maximintegrated.com/packages. Note that a "+", "#", or "-" in the package code indicates RoHS status only. Package drawings may show a different suffix character, but the drawing pertains to the package regardless of RoHS status.

Package thermal resistances were obtained using the method described in JEDEC specification JESD51-7, using a four-layer board. For detailed information on package thermal considerations, refer to www.maximintegrated.com/thermal-tutorial.

Electrical Characteristics

 $(V_{SUP1}=4V,V_{SUP2}=14V,V_{BATTP}=V_{BATTS}=3.5V,T_{A}=T_{J}=-40^{\circ}C\ to+125^{\circ}C, unless otherwise noted.\ Typical values are at\ T_{A}=+25^{\circ}C.)$ (Note 1)

PARAMETER	SYMBOL	CONDITIONS	MIN	TYP	MAX	UNITS
BOOST CONTROLLER						•
Supply Voltage Range	V _{SUP2}	Normal operation	4.5		36	V
Supply Voltage Range		V _{SUP2} t < 1s			40	V
Undervoltage-Lockout Threshold	V _{CSP}	Contact factory for options			2	V
Shutdown Supply Current	I _{SUP2}	Boost disabled through I ² C, V _{SUP2} = 12V, V _{EN1B} = 0V			10	μA
Supply Current	I _{SUP2_STB}	BOOST I ² C bit enabled, V _{EN1B} = 0V, V _{SUP1} = 0 to 6V, V _{SUP2} = V _{SG1} = 14V, no switching	=	26	55	μA
		MAX20094ATIA	6.076	6.2	6.355	
		MAX20094ATIB	6.37	6.5	6.663	
		MAX20094ATIC	6.664	6.8	6.97	1
		MAX20094ATID	6.958	7.1	7.278	
Boost Mode Fixed-Output Voltage	V _{SUP2}	MAX20095ATIA	5.39	5.5	5.7	V
voltage		MAX20095ATIB	7.84	8	8.20	
		MAX20095ATIC	8.82	9	9.27	-
		MAX20095ATID	9.8	10	10.25	
		MAX20095ATIE	11.76	12	12.30	
Boost Output Overvoltage- Falling Threshold (Boost Wakes Up Below this Threshold)	BOOST_OV_F		104	107	110.5	%
Boost Output Overvoltage- Falling Hysteresis				6		%
Boost Output Overvoltage- Rising Threshold (Boost Enters Sleep Mode Above this Threshold)	V _{SUP2_R}		110	113	116	%
D (11) 1 1 1 1	DOT IN # O	Falling		65		0/
Boost Undervoltage Lockout	BST_UVLO	Rising		85		%
Transconductance (from FBB to COMP)	9 _m	V _{BIAS} = 5.5V (Note 2)		250		μS
G1 Drive Strength	G1	V _{SG1} = 6.8V, G1 not active		1.75		kΩ
G1 Activation Time		5nF MOSFET capacitance from SG1 to G1, OV falling until G1 reaches 4.5V below SG1; boost is ready to run within 10µs (typ) once BOOST_OV_F is tripped		10	50	μs
D1 T		DL low to DH rising		20		
Dead Time		DH low to DL rising		20		ns
Minimum On-Time	t _{ON,MIN}			120		ns
Minimum Off-Time	t _{OFF,MIN}			60		ns

Electrical Characteristics (continued)

 $(V_{SUP1} = 4V, V_{SUP2} = 14V, V_{BATTP} = V_{BATTS} = 3.5V, T_A = T_J = -40^{\circ}C$ to +125°C, unless otherwise noted. Typical values are at $T_A = +25^{\circ}C$.) (Note 1)

PARAMETER	SYMBOL	CONDITIONS	MIN	TYP	MAX	UNITS
PWM Switching-Frequency	£		1.9	2.1	2.3	N41.1-
Range	f _{SW}	Contact factory for part number		0.42		MHz
CS_ Current Limit	V _{LIMIT}	V _{CSP} - V _{CSN}	40	50	60	mV
LX Leakage Current		V _{LX} = V _{PGND} or V _{IN} , T _A = +25°C			1	μA
DH Pullup Resistance		V _{BIAS} = 5V, I _{DH} = -100mA		3	6	Ω
DH Pulldown Resistance		V _{BIAS} = 5V, I _{DH} = 100mA		1.5	3	Ω
DL Pullup Resistance		V _{BIAS} = 5V, I _{DL} = -100mA		3	6	Ω
DL Pulldown Resistance		V _{BIAS} = 5V, I _{DL} = 100mA		1.5	3	Ω
INTERNAL LDO BIAS						
Internal BIAS Voltage		V _{SUP2} > 6V		5		V
DIACUNIC TI.		V _{BIAS} rising		3.0	3.25	.,
BIAS UVLO Threshold		V _{BIAS} falling	2.35	2.5		V
BATTERY CHARGER						
Supply Voltage Range	V _{SUP1}		0		6.5	V
Supply Undervoltage Threshold, Falling	V _{SUP1_UV}		3.3			V
Supply Undervoltage Threshold, Rising	V _{SUP1_UV_R}				3.5	V
Supply Leakage Current	I _{SUP1}	Charger disabled, T _A = +25°C			10	μA
SUP1 to BATTP On-Resistance	R _{CHG}	V _{SUP1} = 3.5V, V _{BATTP} = 3.45V		250	500	mΩ
I ² C Control BUB Voltage Setting	V _{CVTHR}	I ² C control	3.0		6.0	V
BUB Voltage Range	V _{BATT}		0.0		6.0	V
Output-Voltage Accuracy	V _{BATT}	V _{CVTHR} = 3.6V	-1.2		+1	%
Fast-Charging Current Setting	_	I ² C settable	0.05		1	Α
Precharge Current		V _{BUB} = 0 to 2.0V	40	50	60	mA
		V _{SUP1} = 3.5V to 6.5V, 250mA < I _{FCHG} < 1A	-10		+10	
Fast-Charge Current Accuracy		V _{SUP1} = 3.5V to 6.5V, 50mA < I _{FCHG} < 250mA	-20		+20	%
Charger Restart-Voltage Threshold		Voltage drop below V _{CVTHR} for FAST_CHR_CC to resume		200		mV
Soft-Start Time		I ² C enables the charger, fast-charge current of 90% of final value; EN1B going from high to low automatically enables the charger, as long as the I ² C register is set			1	ms
BATTP Leakage Current	I _{BATTP}	Not boosting, and/or charger disabled, and/or unpowered (V _{BATT} > V _{SUP1}), T _A = +25°C			1	μA

Electrical Characteristics (continued)

 $(V_{SUP1} = 4V, V_{SUP2} = 14V, V_{BATTP} = V_{BATTS} = 3.5V, T_A = T_J = -40^{\circ}C$ to +125°C, unless otherwise noted. Typical values are at $T_A = +25^{\circ}C$.) (Note 1)

PARAMETER	SYMBOL	CONDITIONS	MIN	TYP	MAX	UNITS
Fast Shut-Off		V _{EN1B} = low to high, overrides l ² C, fast- charge current of < 50mA			5	μs
Minimum Charger Output Capacitance		Backup battery not present	1			μF
IMON Gain				440		A/A
Thermal-Limit Temperature	T _{LIM}	Junction temperature when the charge current is reduced, T_J rising		145		°C
THERMAL OVERLOAD						
Thermal-Shutdown Temperature		(Note 2)		170		°C
Thermal-Shutdown Hysteresis		(Note 2)		20		°C
BATTERY STATE-OF-HEALT	H CURRENT S	INK				
SNK Current Range	I _{SNK}	I ² C control	0		2	А
SNK Current Accuracy		I _{SNK} = 0.5A, V _{BATT} = 3.3V	-10		+10	%
SNK Current-Measurement Accuracy	V _{AVI}	I _{SNK} = 0.5A, V _{BATT} = 3.3V	-7.5	1	+7.5	%
Sink Current-Measurement Voltage Range	V _{AVI}	I _{SNK} = 0A to 2A	0		3	V
BUB Voltage-Measurement Range	V _{AVB}	V _{BATTS} = 0 to 6V	0		6	V
Resistance of AVB Pass Switch		BATT_ to AVB			10	Ω
G2 Drive-Current Capability	I _{G2}		7			μA
BATTS Leakage Current	I _{BATTS}	T _A = +25°C			1	μΑ
SNK Leakage Current	I _{SNK}	T _A = +25°C			1	μΑ
G2 Output Low Voltage	V _{G2_OL}	$I_{G2_SINK} = 5\mu A$			-3	V
BATTS Undervoltage Threshold, Falling					2.5	V
DIGITAL INPUT CHARACTE	RISTICS (SCL,	SDA)				
Input High Threshold	V _{IH}	$2.5V \le V_{DDIO} \le 5.5V$	0.7 x V _{DDIO}			V
Input Low Threshold	V _{IL}	$2.5V \le V_{DDIO} \le 5.5V$			0.3 x V _{DDIO}	V
Input Threshold Hysteresis	V _{HYS}			0.15		V
Input Leakage Current	I _{IN}	$V_{IN} = 0V \text{ or } V_{DDIO}, T_A = +25^{\circ}C$			1	μΑ
Input Capacitance	C _{IN}				10	pF
DIGITAL INPUT CHARACTE	RISTICS (EN1E					
Input High Threshold	V _{IH}	$2.5V \le V_{BIAS} \le 5.5V$	1.4			V


Electrical Characteristics (continued)


 $(V_{SUP1} = 4V, V_{SUP2} = 14V, V_{BATTP} = V_{BATTS} = 3.5V, T_A = T_J = -40$ °C to +125°C, unless otherwise noted. Typical values are at $T_A = +25$ °C.) (Note 1)


PARAMETER	SYMBOL	CONDITIONS	MIN	TYP	MAX	UNITS
Input Low Threshold	V _{IL}	2.5V ≤ V _{BIAS} ≤ 5.5V			0.5	V
Input Leakage Current	I _{IN}	V _{IN} = 0V or V _{BIAS} , T _A = +25°C			1	μA
DIGITAL OUTPUT CHARACT	TERISTICS (SDA	A, STATUSB, BUBTRIG)				
Output High Voltage	V _{OH}	Applies only to BUBTRIG CMOS output, ISOURCE = 1mA	V _{BIAS} - 0.15	V _{BIAS} - 0.06		V
Output Low Voltage	V _{OL}	Applies to SDA, STATUSB, and BUBTRIG; I _{SNK} = 1mA			0.2	V
Output Inactive-Leakage Current	I _{OFF}	Applies only to STATUSB open-drain output (see I _{IN} for SDA)			±1	μA
Output Inactive Capacitance	C _{OFF}	Applies only to STATUSB open-drain output (see C _{IN} for SDA)			10	pF
Backup Battery-Trigger Pulse Width	t _{BUBTRIG}	BOOST enabled and SUP2 < BOOST_OV_F	180	200	220	ms
I ² C-COMPATIBLE INTERFAC	CE TIMING CHA	RACTERISTICS (SCL, SDA)				
SCL Clock Frequency	f _{SCL}		0		400	kHz
Bus-Free Time Between a STOP and START Condition	t _{BUF}		1.3			μs
Hold Time for a Repeated START Condition	t _{HD;STA}		0.6			μs
SCL Pulse Width Low	t _{LOW}		1.3			μs
SCL Pulse Width High	tHIGH		0.6			μs
Setup Time for a Repeated START Condition	t _{SU;STA}		0.6			μs
Data Hold Time	t _{HD;DAT}		0		900	ns
Data Setup Time	t _{SU;DAT}		100			ns
SDA and SCL Receiving Rise Time	t _R	Incoming signals (from master)	20 + C _B /10		300	ns
SDA and SCL Receiving Fall Time	t _F	Incoming signals (from master)	20 + C _B /10		300	ns
SDA Transmitting Fall Time	t _F		20 + C _B /10		250	ns
Setup Time for STOP Condition	tsu;sto		0.6			μs
Bus Capacitance Allowed	C _B	2.5V ≤ V _{DDIO} ≤ 5.5V	0		900	pF
Pulse Width of a Suppressed Spike		Width of spikes that must be suppressed by the input filter of both SDA and SCL signals		50		ns


Note 1: Limits are 100% tested at $T_A = +25$ °C. Limits over the operating temperature range and relevant supply voltage range are guaranteed by design and characterization.


Note 2: Guaranteed by design; not production tested.
























Typical Operating Characteristics (continued)


 $(V_{SUP1} = 4V, V_{SUP2} = 14V, V_{BATTP} = V_{BATTS} = 3.5V, T_A = +25$ °C, unless otherwise noted.)



AMBIENT TEMPERATURE (°C)

Typical Operating Characteristics (continued)

 $(V_{SUP1} = 4V, V_{SUP2} = 14V, V_{BATTP} = V_{BATTS} = 3.5V, T_A = +25$ °C, unless otherwise noted.)




www.maximintegrated.com Maxim Integrated | 10

TIME (HOURS)

SNK CURRENT (mA)

Pin Configuration



Pin Description

PIN	NAME	FUNCTION
1	SUP1	Input to the CC/CV Charger. Connect a 2.2µF ceramic capacitor from SUP1 to the ground plane.
2	BATTP	Charger Output for the Backup Battery (BUB). BATTP is the current sink for the battery state-of-health (SOH) check. Place a 10µF, 2.2µF, and 0.1µF ceramic capacitor as close as possible to the SUP2 pin. See the <i>PCB Layout Recommendations</i> section for details on trace sizing to BATTP.
3	SNK	Connection for the Source of the External MOSFET (M4) for State-of-Health (SOH) Measurements. The SNK pin sinks the preset current from the BUB to the external MOSFET during SOH measurements.
4	G2	Gate Drive to Turn On the MOSFET (M4) and Sink Current Into the IC. This function is controlled by I ² C. G2 is not connected when the discharger is disabled. When the discharger is enabled, G2 is driven to BATTP for 62µs (typ) before the circuit starts up.
5	AVI	Analog Voltage Measurement for SNK Current Set During SOH Measurement. There is a $30k\Omega$ pulldown resistor when AVI is disabled.
6	AVB	Analog Battery Voltage-Measurement Output During SOH Measurements. There is a 60kΩ pulldown resistor connected 10μs before the AVB switch is turned off through I ² C.
7	STATUSB	STATUSB (Battery Boost) Default Open-Drain Output. Driven to AGND during boost operation due to loss of primary power; otherwise, high impedance.
8	BUBTRIG	Backup Battery-Active Timed Output. Driven to BIAS for 200ms following backup boost controller start of operation; otherwise, driven to AGND.
9	EN1B	Charger Disable. EN1B is connected to ground during normal operation. If pulled high, the charger is disabled, regardless of the I ² C register setting.

Backup Battery Charger and Boost Controller

Pin Description (continued)

PIN	NAME	FUNCTION				
10	VDDIO	I ² C Logic Interface Supply Voltage, 2.5V to 5.5V. Connect to the I ² C bus supply.				
11	SDA	C Data Signal				
12	SCL	I ² C Clock Input				
13	N.C.	Connect to GND in the Application				
14	G1	High-Side p-Channel MOSFET (M3) Driver. There is a 188kΩ resistor between G1 and SG1.				
15	SG1	Source of the External p-Channel MOSFET (M3). SG1 and G1 control the gate drive of external MOSFET M3.				
16	SUP2	System Supply Voltage Input. High-voltage-tolerant input to the LDO, which generates 5V supply for the IC. Connect a resistor and capacitor filter from the battery-filtered rail and SUP2. See the <i>Applications Information</i> section for more details.				
17	PGND	Power Ground Pin. Connect directly to the PCB ground plane.				
18	DL	Low-Side MOSFET Driver Output. Connect to the gate of the boost converter's low-side MOSFET.				
19	DH	High-Side MOSFET Driver Output. Connect to the boost converter's high-side MOSFET.				
20	LX	Switching Node of DC-DC Controller				
21	BST	Boosted Supply Voltage for the High-Side Sync MOSFET Gate Drive				
22	CSN	Current-Sense Resistor, Inductor-Side Sense Point. Connect CSN as close as possible to the current-sense resistor terminal. See the <i>PCB Layout Recommendations</i> section for details on proper layout.				
23	CSP	Current-Sense Resistor Input Pin. Connect CSP as close as possible to the current-sense resistor for accurate current sensing. See the <i>PCB Layout Recommendations</i> section for details on proper layout.				
24	COMP	Loop-Compensation Component Connection Pin. COMP is the output of the internal g _m amplifier. Connect a resistor in series with a capacitor to the AGND pin. The component values are selected according to the data sheet recommendations.				
25	IMON	Connect IMON to GND with a 500 Ω Resistor. $V_{IMON} = (I_{CHG}/440) \times 500\Omega$. Max $R_{IMON} = (V_{BATTP(MIN)} - 0.25)/(0.0025I_{CHG}) - 200$.				
26	BIAS	Supply Pin for the Internal IC Circuits. This pin should be decoupled with a 2.2µF capacitor. BIAS is the output of the LDO connected to the V _{SUP} pin, and is used to supply the internal circuitry with 5V.				
27	AGND	Analog Ground. Low-noise ground for precision circuit blocks.				
28	BATTS	Battery Voltage-Sensing Input. Senses the battery voltage for the voltage-feedback loop and routes to the internal analog switch. Connect BATTS as close as possible to the battery's positive terminal for the most accurate voltage sensing of the battery.				
_	EP	Exposed Pad				

Detailed Description

The MAX20094/MAX20095 ICs combine a configurable constant-current/constant-voltage (CC/CV) battery charger, with a high-efficiency synchronous boost controller to supply critical systems in the event the primary power source is lost. In addition, diagnostic features are available to check battery state-of-health (SOH) and IC functionality. Charging thresholds and the boost output voltage are configurable to support popular battery chemistries and a wide range of cell counts. To support system integration, the ICs have an I²C slave port through which configuration and status bits can be accessed.

BIAS Linear Regulator

An internal 5V linear regulator (BIAS) generates a bias supply for the internal circuitry. Bypass BIAS with a $2.2\mu F$ or greater ceramic capacitor to guarantee stability under the full-load condition.

The BIAS input undervoltage-lockout (UVLO) circuitry inhibits boost operation, charging, or SOH if the 5V bias supply (BIAS) is below its 2.5V (typ) UVLO falling threshold. Once the 5V bias supply (BIAS) rises above its UVLO rising threshold and the block control logic conditions are met, the ICs are functional.

Block Control Logic

The logic governing the operation of the boost controller, battery charger, and SOH is summarized in Table 1.

Logic Equations

STATUSB Pin

The STATUSB pin is an open-drain, active-low nMOS output pin that can be used in a shared-interrupt configuration with a μ C master, and any number of similarly configured slave devices (using a wired-OR configuration with an external pullup resistor to a suitable supply, typically V_{DDIO}). Under default conditions, the STATUSB pin is active when the boost is actively regulating SUP2. The function of the STATUSB pin can be changed to provide other types of operation using the I²C interface (see the GEN_STATUS and EN_INT registers).

Charger Block

The normal operating mode of the ICs is to maintain charge on the backup battery (BUB). This function is provided by the charger block.

Table 1. Block Control Logic

BLOCK	COMMENTS			
SOH	SOH is enabled when: I ² C register bit is set, and Boost is not regulating, and Not in thermal-shutdown condition			
Boost	Boost is enabled/regulating when: • I ² C register bit is set, and • SUP2 is below OV_F threshold • Not in thermal-shutdown condition Note:When boost is regulating, SOH and charger functions are disabled.			
Charger	Charger is enabled when: • I ² C register bit is set and EN1B pin = 0 • Boost is not regulating, and			
	Note: While enabled, the charger mode progression is controlled by an internal state machine and associated comparators.			




Figure 1. Charger Block Diagram

Charger State Machine Description

Once enabled, the charger operation is governed by a state machine, described below and detailed in <u>Figure 2</u>. The real-time operation of the charger can be read back using the CHGR_STATUS (01\h) register.

The charger is held in an OFF state when CONTROL/CHG_EN=0, or START_BIASRDY=0, or the die temperature is above the thermal-shutdown threshold. Once CONTROL/CHG_EN=1, bias has been established (START_BIASRDY=1) and the die temperature is below the thermal-shutdown threshold (START_THMSD=0), the charger moves to standby mode, and a $15\mu S$ timer is started, allowing the charger's internal biases and comparators to settle.

The charger remains in standby mode until internal biases are established (based on the startup timer) and supply conditions are checked and found to be valid. The charger returns to standby mode in the event of an invalid supply condition. Supply conditions can be verified in real time using the CHGR_STATUS (01\h) register. A supply condition alert is also available in GEN STATUS (02\h).

The charger next moves to a 50mA current-limited charging mode (PREQUAL). The charger remains in this mode until V_{BUB} exceeds V_{PQVTHR} , which is factory set to 2V. Contact the factory for different settings.

The charger now begins the fast-charging procedure, beginning in a constant-current mode (FAST_CHG_CC). Charge current is programmed using the CHGR_CC (05\h) register. The charger remains in fast charging until VBUB exceeds VCVTHR and returns to FAST_CHG_CC if VBUB falls below VCVTHR, which is selected using the CHGR_CV (06\h) register.

When V_{BUB} exceeds V_{CVTHR} , the charger continues charging in a constant-voltage mode (FAST_CHG_CV). A constant-voltage-mode alert is available in GEN_STATUS (02\h), notifying the user that charging is nearing completion. Once the charger has moved to FAST_CHG_CV mode, the charger current is monitored. If I_{CHG} falls below 50mA, the fast-charging operation is completed and the charger moves to FAST_CHG_DONE mode. The charger remains in this mode until it is disabled by the user (returning to OFF), a supply fault condition occurs (returning to STANDBY), or V_{BUB} falls below V_{CVTHR} - 200mV (returning to FAST_CHG_CC). After entering the DONE state, a charging-done alert is available in GEN_STATUS (02\h), notifying the user that charging is completed.

If V_{SUP1} and V_{BUB} enter dropout, the charge current is reduced due to the $R_{DS(ON)}$ of the internal MOSFET, and the voltage difference between V_{SUP1} and the battery. If charge current continues to decrease, the ALRT_CV and CHGR_MODE changes to show CV state. Once charge current reduces to 50mA, ALRT_CV remains 1, ALRT_DONE=1, and CHGR_MODE goes to the DONE state. Use the following equation to estimate the amount of headroom required to stay out of dropout at maximum ambient temperature:

where $R_{CHG\ MAX}$ is the maximum value of $R_{CHG\ from\ the\ Electrical\ Characteristics}$ table.

When CONTROL/CHG_EN=0, then CHRG_STATUS/SUP1_UVLO=1. This default condition is due to internal circuitry being turned off to minimize leakage.

EN1B Pin

The EN1B pin is an active-low input port that controls the operation of the charger block. When the EN1B pin is held low, the charger operation is controlled by the I²C interface registers. When pulled high (usually due to an external system fault), the charger is instantly disabled and its internal state machine reset. The charger resumes normal operation once the pin is returned low.




Figure 2. Charger State Machine Diagram

Boost Block

The boost block allows the ICs to maintain a regulated supply voltage on the SUP2 pin using the backup battery (BUB) in the event of a main-battery failure.

The boost is a synchronous current-mode controller with a factory-preset output voltage. The switching frequency is capable of greater than 2MHz. To enable longer battery life, the boost utilizes pulse-frequency modulation (PFM) mode at light load and automatically enters ultra-low IQ standby mode when output voltage is above the required boost voltage. The boost automatically enters awake mode when the output voltage is at or near the required boost voltage, and sends a discrete signal to the host to indicate it has awakened.

Standby Current

The ICs have low standby supply current, as mentioned in the <code>Electrical Characteristics</code> table, but still allow for 250µs (max) quick turn-on time once V_{SUP2} falls below BST_OV_F. I²C settings are held during the low-standby mode. In this mode, MOSFET M3 (see <code>Figure 3</code>) is OFF until the boost's overvoltage (OV) falling threshold triggers, and then it turns ON.

BUBTRIG Pin

BUBTRIG is an active-low, 200ms one-shot CMOS output used to indicate the start of a period of active regulation by the boost block. When the boost is enabled and begins regulating (due to V_{SUP2} falling below the BOOST_OV_F voltage threshold), BUBTRIG is asserted high for 200ms before going low again (even if the boost block continues regulation duties beyond 200ms). BUBTRIG is not asserted again unless the boost block exits active regulation mode and later resumes regulation activity.

Current Limit

A current-sense resistor (R_{CS}), connected to the CSP and CSN pins, sets the current limit of the boost converter. The CS_ input has a voltage trip level (V_{LIMIT}) of 50mV (typ). The low 50mV current-limit threshold reduces the power dissipation in the current-sense resistor. Use a current-sense filter to reduce noise in the current-sense path (see the *Shunt Resistor Selection* section).

Skip Operation

Skip mode is enabled with BST_SKIP=1. The transition from pulse-width modulation (PWM) to skip mode occurs as load current is reduced and LX current drops below zero crossing and eventually reaches $t_{\mbox{ON MIN}}$. Once




Figure 3. Boost Block Diagram

zero crossing and one cycle of t_{ON_MIN} are reached, the controller enters skip mode. Transition back to PWM mode occurs when there is 480ns of t_{ON_MIN} and the output voltage stays too low, so PWM control resumes to bring output voltage back into regulation.

State-of-Health Block

The state-of-health (SOH) block (see Figure 4) allows the ICs to test the backup battery (BUB) under current-load conditions to aid in determining the condition of the BUB based on output impedance. During the test, the output voltage of the battery, as well as a voltage representation of the current applied, are made available for ADC measurements. When V_{BUB} is less than 2.5V, the SOH discharger is disabled and the SOH_ILIM status bit is set to 1, indicating that a fault has occurred. The SOH sink current setting is the SOH (07/h) register. SOH is enabled by setting CONTROL/SOH_EN. Selection between the

hardware-default and register-override values are set by CONTROL/SOH OVR.

AVB Switch

The AVB switch passes the BATTS sense voltage to the AVB pin. This allows voltage monitoring of the BUB. Resistance of the AVB pass switch is defined in the *Electrical Characteristics* table.

AVI Switch

The AVI switch is an analog output representing the sink current during the SOH measurement. V_{AVI} typically reads 1.5V/A of SOH current.

I²C Interface

Communication with the ICs is achieved using an I²C-compatible serial interface. This interface allows the user to configure and monitor the operation of the device.




Figure 4. State-of-Health Block Diagram

Serial Addressing

The I²C port operates as slave devices, which send and receive data through an I²C-/SMBus-compatible 2-wire serial interface. The interface uses a serial-data access (SDA) line and a serial-clock line (SCL) to achieve bidirectional communication between master(s) and slave(s) devices. A master (typically a microcontroller) initiates all data transfers to the port and generates the SCL clock that synchronizes the data transfer.

The SDA line operates as both an input and an open-drain output. The SDA line requires a pullup resistor (4.7kW, typ). The port's SCL line operates only as an input. The SCL line requires a pullup resistor (4.7kW, typ) if there are multiple masters on the 2-wire interface, or if the master in a single-master system has an open-drain SCL output.

Each transmission consists of a START (S) condition sent by a master, followed by the core's 7-bit slave address plus the NOP/W bit, one command/register byte, one data byte, and a STOP (P) condition.

I²C Bit Transfer

One data bit is transferred during each SCL cycle. The data on SDA must remain stable during the high period of the SCL pulse. Changes in SDA while SCL is high are control signals (see the <u>I2C START and STOP Conditions</u> section).

I²C START and STOP Conditions

SDA and SCL idle high when the bus is not in use. A master initiates communication by issuing a START condition. A START condition is a high-to-low transition on SDA with SCL high. A STOP condition is a low-to-high transition on SDA while SCL is high. A START condition from the master signals the beginning of a transmission to the device. The master terminates transmission, and frees the bus, by issuing a STOP condition.

The bus remains active if a Repeated START condition is generated instead of a STOP condition; this is often used in combined-format read operations. See <u>Figure 5</u> for examples that show the generation and proper use of START (S), STOP (P), and Repeated START (Sr) conditions.

I²C Acknowledge

The acknowledge bit (ACK) is a clocked 9th bit the device uses for handshake receipt of each byte of data when in write mode. The device pulls down SDA during the entire master-generated 9th clock pulse if the previous byte is successfully received. Monitoring ACK allows the detection of unsuccessful data transfers that occur if a receiving device is busy, or if a system fault has occurred. In the event of an unsuccessful data transfer, the bus master retries communication. The master pulls down SDA during the 9th clock cycle to acknowledge receipt of data when the device is in read mode. An acknowledge is sent by the master after each read byte to allow data transfer to continue. A not-acknowledge (NACK) is sent when the master reads the final byte of data from the device, followed by a STOP (P) condition.




Figure 5. I²C Serial-Interface Timing Diagram

I²C Command and Data Bytes

A command byte follows the slave address. A command byte is typically followed by one or two data bytes unless it is the last byte in the transmission, as would be the case for readback operations (see Figure 5). If data bytes follow the command byte, the command byte indicates the address of the register that should receive the data bytes that follow. The data bytes are stored in a temporary register and then transferred to the appropriate register during the ACK periods between bytes.

I²C Write Operations

A master device communicates with the device by transmitting the proper slave address, followed by a register/command and data word(s). Each transmit sequence is framed by a START (S) or Repeated START (Sr) condition and a STOP (P) condition. Each byte is 8 bits long and is always followed by an acknowledge (ACK) clock pulse, as shown in Figure 6. The first byte contains the

address of the device, with $R/\overline{W} = 0$ to indicate a write. The second byte contains the register (or command) to be written, and the third byte contains the data to be written.

I²C Read Operations

The ICs support standard combined-format I 2 C readmode operations. Each receive sequence is again framed by a START (S) or Repeated START (Sr) condition and a STOP (P). Each byte is 8 bits long and is always followed by an ACK clock pulse, as shown in Figure 7. The first byte contains the address of the device, with R/W = 0 to indicate a write. The second byte contains the register that is to be read back. There is now a Repeated START (Sr) condition, followed by the device address, with R/W = 1 to indicate a read and an acknowledge (ACK) clock. The master still has control of the SCL line, but the device takes over the SDA line. The fourth byte in the frame contains the register data readback followed by a STOP (P) condition.




Figure 6. I²C Write Sequence




Figure 7. I²C Read Sequence

I²C User Command and Register Map

AD- DRESS	NAME	MSB	•						LSB
USER CO	MMANDS				l	ı	<u> </u>		
0x00	CHIP_ID[7:0]				DIE_TY	PE[7:0]			
0x01	CHGR_STATUS[7:0]	CHGR_ EN	- CHGR MODELY:01			-	SUP1_ UVLO	SUP1_ OVP	SUP1_ BATT
0x02	GEN_STATUS[7:0]	BOOST	ALRT_ BST	ALRT_ CV	ALRT_ DONE	ALRT_ SUP1	THRM_ LIM	THRM_ SD	SOH_ ILIM
0x03	EN_INT[7:0]	EN_BST	EN_ ABST	EN_ACV	EN_ADN	EN_ASP	EN_TLIM	EN_TSD	EN_ SOHI
0x04	CONTROL[7:0]	SOH_EN	SOH_ OVR	AVI_EN	AVB_EN	CHG_EN	CHG_ IMON	BST_EN	BST_ SKIP
0x05	CHGR_CC[7:0]	_	_	_		FC	HG_CUR[4	:0]	
0x06	CHGR_CV[7:0]	-	_	_	VCVTHR[4:0]				
0x07	SOH[7:0]	ISINK[3:0] REG_ISINK[3:0]							
0x08	SW_RST[7:0]	All_Zeros[7:0]							
0xFF	NO_OP[7:0]				Dont_C	are[7:0]			

CHIP_ID (0x00)

CHIP_ID is a read-only register that provides information on the chip and silicon revision.

BIT	7	6	5	4	3	2	1	0	
Field		DIE_TYPE[7:0]							
Reset		0x02 for MAX20094 and 0x03 for MAX20095							
Access Type		Read Only							

BITFIELD	BITS	DESCRIPTION
DIE_TYPE	7:0	DIE_TYPE provides information on the chip and silicon revision.

Backup Battery Charger and Boost Controller

CHGR_STATUS (0x01)

CHGR_STATUS is a read only register that provides information on the Charger operating mode and related Supply1 voltage status.

BIT	7	6	5	4	3	2	1	0
Field	CHGR_EN	CHGR_MODE[2:0]			-	SUP1_ UVLO	SUP1_OVP	SUP1_ BATT
Reset								
Access Type	Read Only		Read Only			Read Only	Read Only	Read Only

BITFIELD	BITS	DESCRIPTION
CHGR_EN	7	0 = Disabled: CONTROL/CHG_EN=0, or BIAS is below UVLO threshold. 1 = Enabled: CONTROL/CHG_EN=1, and BIAS is above UVLO threshold.
CHGR_MODE	6:4	0b000 = Disabled/standby 0b010 = Prequalify-Charging Mode:
SUP1_UVLO	2	$0 = V_{SUP1} > 3.5V$ $1 = V_{SUP1} < 3.5V$ Note: 1 when CHG_EN=0.
SUP1_OVP	1	$0 = V_{SUP1} < 7.0V$ $1 = V_{SUP1} > 7.0V$
SUP1_BATT	0	0 = V _{SUP1} > (V _{BATT} + 100mV) 1 = V _{SUP1} < (V _{BATT} + 100mV)

Backup Battery Charger and Boost Controller

GEN_STATUS (0x02)

GEN_STATUS is a read-only register that provides information on the status and operation of all internal blocks within the ICs. The contents of the GEN_STATUS register can be individually selected for inclusion in the STATUS/INTB interupt term using the EN_INT register.

BIT	7	6	5	4	3	2	1	0
Field	BOOST	ALRT_BST	ALRT_CV	ALRT_ DONE	ALRT_ SUP1	THRM_LIM	THRM_SD	SOH_ILIM
Reset								
Access Type	Read Only	Read Only	Read Only	Read Only	Read Only	Read Only	Read Only	Read Only

BITFIELD	BITS	DESCRIPTION
BOOST	7	0 = Disabled: CONTROL/BST_EN = 0, or V _{SUP2} > V _{BOOST_OV_F} 1 = Enabled: CONTROL/BST_EN = 1 and V _{SUP2} < V _{BOOST_OV_F} Note: Boost threshold is set through OTP.
ALRT_BST	6	0 = Boost has not been activated since the last read. 1 = Boost has been activated since last the read. Edge-Set, Clear-on-Read: Once read, this alert is cleared until the boost is deactivated and reactivated. Real-time boost activity can be monitored using D7.
ALRT_CV	5	0 = Charger has not reached fast-charge CV mode since the last read. 1 = Charger has reached fast-charge CV mode since the last read. Edge-Set, Clear-on-Read: Onceread, this alert is cleared until the charger exits and reenters the CV state.
ALRT_DONE	4	0 = Charger has not reached fast-charge-done mode since the last read. 1 = Charger has reached fast-charge-done mode since the last read. Edge-Set, Clear-on-Read: Onceread, this alert is cleared until the charger exits and reenters the done state.
ALRT_SUP1	3	0 = Supply1 conditions allow normal charger operation. 1 = One or more supply status indicators is active. Level-Set, Clear-on-Read: Once read, this alert is cleared if the supply condition has been resolved. Individual supply faults can be read back using CHGR_STATUS.
THRM_LIM	2	0 = Charger is not operating, or is operating normally. 1 = Charger is operating in a thermally limited (reduced-current) mode (> 135°C). Level-Set, Clear-on-Read: Once read, this alert is cleared if the thermal-limit condition has been resolved.
THRM_SD	1	0 = Device is operating normally. 1 = Device thermal protection is engaged (> 170°C). Level-Set, Clear-on-Read: Onceread, this alert is cleared if the thermal-shut-down condition has been resolved.
SOH_ILIM	0	0 = SOH is not operating, or is operating normally (I _{SNK} < 3A, or V _{BATTP} > undervoltage threshold). 1 = SOH is operating in overcurrent condition (I _{SNK} ≥ 3A, or V _{BATTP} > undervoltage threshold). Level-Set, Clear-on-Read: Once read, this alert is cleared if the overcurrent condition, or BATTP undervoltage condition has been resolved.

EN_INT (0x03)

EN_INT is a read/write register that governs the operation of the STATUSB output pin. The content of this register determines which interrupt input terms are included in the interrupt output OR term (e.g., a '1' in an EN_INT register indicates that the corresponding input term is included in the STATUS interrupt output OR term). See the GEN_STATUS register for detailed descriptions of the interrupt terms.

BIT	7	6	5	4	3	2	1	0
Field	EN_BST	EN_ABST	EN_ACV	EN_ADN	EN_ASP	EN_TLIM	EN_TSD	EN_SOHI
Reset	0b1	0b0						
Access Type	Write, Read							

BITFIELD	BITS	DESCRIPTION
EN_BST	7	0 = BOOST status is not included in the STATUS OR term. 1 = BOOST status is included in the STATUS OR term.
EN_ABST	6	0 = ALRT_BST status is not included in the STATUS OR term. 1 = ALRT_BST status is included in the STATUS OR term.
EN_ACV	5	0 = ALRT_CV status is not included in the STATUS OR term. 1 = ALRT_CV status is included in the STATUS OR term.
EN_ADN	4	0 = ALRT_DONE status is not included in the STATUS OR term. 1 = ALRT_DONE status is included in the STATUS OR term.
EN_ASP	3	0 = ALRT_SUP1 status is not included in the STATUS OR term. 1 = ALRT_SUP1 status is included in the STATUS OR term.
EN_TLIM	2	0 = THRM_LIM status is not included in the STATUS OR term. 1 = THRM_LIM status is included in the STATUS OR term.
EN_TSD	1	0 = THRM_SD status is not included in the STATUS OR term. 1 = THRM_SD status is included in the STATUS OR term.
EN_SOHI	0	0 = SOH_ILIM status is not included in the STATUS OR term. 1 = SOH_ILIM status is included in the STATUS OR term.

CONTROL (0x04)

CONTROL is a read/write register that enables/disables device features.

BIT	7	6	5	4	3	2	1	0
Field	SOH_EN	SOH_OVR	AVI_EN	AVB_EN	CHG_EN	CHG_IMON	BST_EN	BST_SKIP
Reset	0b0	0b1						
Access Type	Write, Read							

BITFIELD	BITS	DESCRIPTION
BITTILLD	ытэ	0 = SOH disabled, G2 driven to BATTP.
SOH_EN	7	1 = SOH enabled, G2 driven to achieve I _{SNK} (V _{BATTP} to AGND - 3V). Notes: This bit is reset to 0 when the boost controller is actively regulating (BST_EN=1 and SUP2 < BST_OV_F threshold). This bit is reset to 0 when SOH current limit is true, or V _{BATTP} is undervoltage.
SOH_OVR	6	0 = Use Hardware default value, ISINK[3:0] = OTP_ISINK[3:0]. 1 = Use override value, ISINK[3:0] = REG_ISINK[3:0]. Note: This bit allows toggling between the OTP and REG settings of ISINK.
AVI_EN	5	0 = Switch off. 1 = Switch on.
AVB_EN	4	0 = Switch off. 1 = Switch on.
CHG_EN	3	0 = Charger disabled. 1 = Charger enabled (if EN1B is also low). Notes: The register value is programmed and read back in this location; the AND term showing the charger-enable status is available as CHGR_STATUS/CHGR_EN. This bit is reset to 0 when the boost controller is actively regulating (BST_EN=1 and SUP2 < BST_OV_F threshold).
CHG_IMON	2	0 = Internally shunting current. 1 = Current is sent to the IMON pin (monitoring current .externally).
BST_EN	1	0 = Boost controller disabled. 1 = Boost controller enabled. Notes: This bit is reset to 0 if all the following conditions are true: - boost controller is actively regulating (BST_EN=1 and SUP2 < BST_OV_F threshold) SUP2 < 4.5V (BST_UV threshold).
BST_SKIP	0	0 = Disable boost skip-mode operation. 1 = Enable boost skip-mode operation.

Backup Battery Charger and Boost Controller

CHGR_CC (0x05)

CHGR_CC is a read/write register that sets the fast-charge current during constant-current operation.

BIT	7	6	5	4	3	2	1	0
Field	-	_	_		F	CHG_CUR[4:0)]	
Reset	-	_	-	0x0				
Access Type	_	_	_			Write, Read		

BITFIELD	BITS	DESCRIPTION
FCHG_CUR	4:0	FCHG_CUR sets the fast-charge current between 50mA and 1000mA in 50mA steps 0b00000 = 50mA 0b00001 = 100mA 0b00010 = 150mA 0b10001 = 900mA 0b10010 = 950mA 0b10011 = 1000mA 0b11111 = 1000mA Notes: Prior to initial write, FCHG_CUR reads back the factory-default setting. The reset value is determined by OTP (0b00000 = 50mA).

CHGR_CV (0x06)

CHGR_CV is a read/write register that sets the charger regulation voltage required to shift to constant-voltage operation.

BIT	7	6	5	4	3	2	1	0
Field	_	_	_			VCVTHR[4:0]		
Reset	-	-	-			0x0		
Access Type	_	_	_			Write, Read		

BITFIELD	BITS	DESCRIPTION
VCVTHR	4:0	VCVTHR sets the charger regulation between 3.0V and 6.0V in 100mV steps: 0b00000 = 3.0V 0b00001 = 3.1V 0b00010 = 3.2V 0b11100 = 5.8V 0b11101 = 5.9V 0b11111 = 7.0V Note: The reset value is determined by OTP (0b00110=3.6V).

SOH (0x07)

SOH is a read/write register that sets the user-programmable sink current during state-of-health (SOH) measurements. Enabling of SOH is accomplished by setting CONTROL/SOH_EN. Current selection between hardware-default and register-override values is set by CONTROL/SOH_OVR (Reg03\h, D6 and D5, respectively). Writes to this register are only required to modify the register-override value, REG_ISINK[3:0]. To support dual-current measurements, this register should be written before the override value is used. Readback of the SOH register returns the ISINK[3:0] value currently in use (read only, depending on the value of CONTROL/SOH_OVR), and the user-programmed value of REG_ISINK[3:0] (for verification).

BIT	7	6	5	4	3	2	1	0
Field		ISINI	< [3:0]		REG_ISINK[3:0]			
Reset					0b0000			
Access Type		Read	Only			Write,	Read	

BITFIELD	BITS	DESCRIPTION
ISINK	7:4	If CONTROL/SOH_OVR = 0, OTP_ISINK[3:0] is returned. If CONTROL/SOH_OVR = 1, REG_ISINK[3:0] is returned. 0b0000 = 125mA.
REG_ISINK	3:0	REG_ISINK sets the discharger's current regulation between 125mA and 2A in 125mA steps: 0b0000 = 125mA 0b0001 = 250mA 0b0010 = 375mA 0b1101 = 1.750A 0b1110 = 1.875A 0b1111 = 2A

SW_RST (0x08)

SW_RST (software reset) is a write-only register/command that resets the entire part to its original default conditions at the end of the I²C SW_RST transaction (i.e., the data-byte ACK). Execution only occurs if DIN[7:0]=0x00. The effect of a SW_RST is identical to power-cycling the part.

BIT	7	6	5	4	3	2	1	0
Field	All_Zeros[7:0]							
Reset	0b00000000							
Access Type		Write Only						

BITFIELD	BITS	DESCRIPTION
All_Zeros	7:0	

NO_OP (0xFF)

NO_OP (no-operation register) is a read-write register that has no internal effect on the part. If this register is read back, SDA remains zero for I²C readback data. Any attempt to write to this register is ignored, without impact to internal operation.

BIT	7	6	5	4	3	2	1	0
Field	Dont_Care[7:0]							
Reset	0x00							
Access Type		Write Only						

BITFIELD	BITS	DESCRIPTION
Dont_Care	7:0	

Applications Information

Boost Converter

Boost switching current is sensed by R1 in the <u>Simplified Block Diagram</u>. During large loads, the limits of the CSN, CSP, and the headroom available on the amplifier need to be observed. The V_{LIMIT} is shown in the <u>Electrical Characteristics</u> table. For a 0.003Ω (typ) sense resistor and 40mV (min) V_{LIMIT} , the peak inductor current is 13.3A. As the BUB is depleted of charge, the CSP pin voltage decreases. When the undervoltage lockout on CSP is disabled, the CSP low voltage for minimum headroom is 1.5V (typ), assuming $100\text{m}\Omega$ battery ESR and 3.2V.

Inductor Selection

Duty cycle and frequency are important to calculate the inductor size, as the inductor current ramps up during the on-time of the switch and ramps down during its off-time. A higher switching frequency generally improves transient response and reduces component size; however, if the boost components are used as the input filter components during nonboost operation, low frequency becomes advantageous.

The duty-cycle range of the boost converter depends on the effective input-to-output voltage ratio. In the following calculations, the duty cycle refers to the on-time of the boost MOSFET:

$$D_{MAX} = \frac{V_{OUT(MAX)} - V_{BUB(MIN)}}{V_{OUT(MAX)}}$$

or including the voltage drops across the inductor, MOSFET ($V_{\mbox{ON,FET}}$):

$$D_{MAX} = \frac{V_{OUT(MAX)}^{-V} BUB(MIN)^{+I} OUT \times R}{V_{OUT(MAX)}}$$

where:

$$R = R_{DC} + R_{DSON M2} + R_{DSON M3}$$

The ratio of the inductor peak-to-peak AC current to DC average current (LIR) must be selected first. A good initial value is a 30% peak-to-peak ripple current to average

current ratio (LIR = 0.3). The switching frequency, input voltage, output voltage, and elected LIR determine the inductor value as follows:

$$L[\mu H] = \frac{V_{IN} \times D}{f_{SW}[MHz] \times LIR}$$

where:

D =
$$(V_{OUT} - V_{IN})/V_{OUT}$$

 V_{IN} = Typical input voltage
 V_{OUT} = Typical output voltage
LIR = 0.3 x $I_{OUT}/1$ - D

Select the inductor with a saturation current rating higher than the peak-switch current limit of the converter:

$$I_{L, PEAK} > I_{L, MAX} + \frac{\Delta I_{L, RIP, MAX}}{2}$$

Running a boost converter in continuous-conduction mode introduces a right-half-plane zero into the transfer function. To avoid the effect of this right-half-plane zero, the crossover frequency for the control loop should be \leq 1/3 x f_{RHP_ZERO}. If faster bandwidth is required, a smaller inductor and higher switching frequency is recommended.

MOSFET Selection

The key selection parameters for choosing the n-channel MOSFET used in the boost converter follow.

Threshold Voltage

The boost's n-channel MOSFET must be a logic-level type with guaranteed on-resistance specifications at V_{GS} = 4.5V.

Current Capability

The n-channel MOSFET must deliver the input current $(I_{IN(MAX)})$:

$$I_{IN(MAX)} = I_{LOAD(MAX)} \times \frac{D_{MAX}}{1 - D_{MAX}}$$

Choose MOSFETs with the appropriate average current at $V_{GS} = 4.5V$.

Input Capacitor Selection

The BUB provides the voltage on the input and some stability to transients, but can include a wiring harness or series resistance. Add a $10\mu F$, $2.2\mu F$, and $0.1\mu F$ X7R ceramic capacitor at the BATTP input of the MAX20094. Review the MAX20094 Evaluation Kit schematic and PCB layout with the factory to optimize the input capacitors.

The input current for the boost converter is continuous and the RMS ripple current at the input capacitor is low. Calculate the minimum input capacitor value and the maximum ESR using the following equations:

$$C_{BUB} = \frac{\Delta I_L \times D}{4 \times f_{SW} \times \Delta V_Q}$$

$$ESR = \frac{\Delta V_{ESR}}{\Delta I_{L}}$$

where:

$$\Delta I_{L} = \frac{\left(V_{BUB} - V_{DS}\right) \times D}{L \times f_{SW}}$$

 V_{DS} is the total voltage drop across the external MOSFET, plus the voltage drop across the inductor ESR. ΔI_L is the peak-to-peak inductor ripple current as calculated above. ΔV_Q is the portion of input ripple due to the capacitor discharge and ΔV_{ESR} is the contribution due to ESR of the capacitor. Assume the input capacitor-ripple contribution due to ESR (ΔV_{ESR}) and capacitor discharge (ΔV_Q) are equal when using a combination of ceramic and aluminum capacitors. During the converter turn-on, a large current is drawn from the input source, especially at a high output-to-input differential.

Output Capacitor Selection

In a boost converter, the output capacitor supplies the load current when the boost MOSFET is on. The required output capacitance is high, especially at higher duty cycles. Also, the output capacitor ESR needs to be low enough to minimize the voltage drop while supporting the load current. Use the following equations to calculate the output capacitor for a specified output ripple. All ripple values are peak-to-peak:

$$ESR = \frac{\Delta V_{ESR}}{I_{OUT}}$$

$$C_{OUT} = \frac{I_{OUT} \times D_{MAX}}{\Delta V_{O} \times f_{SW}}$$

 I_{OUT} is the load current in A, f_{SW} is in MHz, C_{OUT} is in μ F, ΔV_Q is the portion of the ripple due to the capacitor discharge, and ΔV_{ESR} is the contribution due to the ESR of the capacitor. D_{MAX} is the maximum duty cycle at the minimum input voltage. Use a combination of low-ESR ceramic, and high-value low-cost aluminum capacitors for lower output ripple and noise.

Shunt Resistor Selection

The current-sense resistor (R_{CS}_), connected between the battery and the inductor, sets the current limit. The CS_ input has a voltage trip level (V_{CS}_) of 50mV (typ). Set the current-limit threshold high enough to accommodate the component variations. Use the following equation to calculate the value of R_{CS}:

$$R_{CS_{-}} = \frac{V_{CS_{-}}}{I_{IN(MAX)}}$$

where $I_{IN(MAX)}$ is the peak current that flows through the MOSFET at full load and minimum V_{IN} .

$$I_{IN(MAX)} = I_{LOAD(MAX)} / (1 - D_{MAX})$$

When the voltage produced by this current (through the current-sense resistor) exceeds the current-limit comparator threshold, the MOSFET driver (DL) quickly terminates the on-cycle.

Input Filter for SUP2

An input filter consisting of a $10\mu F$ capacitor and $100m\Omega$ resistor is suggested. SUP2 current is approximately 50mA for boost applications in FPWM mode, $300\mu A$ in skip mode, and $26\mu A$ in standby mode. For charger and SOH applications, SUP2 current is approximately 1mA.

PCB Layout Recommendations

Careful PCB layout is critical to achieve low switching losses and clean, stable operation. The switching power stage requires particular attention (see <u>Figure 5</u>). When possible, mount all power components on the top side of the board, with their ground terminals flush against one another. Follow these guidelines for good PCB layout:

- Keep the high-current paths short, especially at the ground terminals. This practice is essential for stable, jitter-free operation.
- Keep the power traces and load connections short.
 This practice is essential for high efficiency. Using thick copper PCBs (2oz vs. 1oz) can enhance full-load efficiency by 1% or more.

- Minimize current-sensing errors by connecting CSP and CSN. Use kelvin sensing directly across the current-sense resistor (R_{CS}).
- Route high-speed switching nodes (BST_, LX_, DH_, and DL_) away from sensitive analog areas (SUP2, CSP, and CSN).

PCB Layout Procedure

- Place the power components first, with ground terminals adjacent (low-side FET, C_{IN}, C_{OUT}, and Schottky). If possible, make all these connections on the top layer with wide, copper-filled areas.
- Mount the controller IC adjacent to the low-side MOSFET (preferably on the back side opposite NL_ and NH_) to keep LX, GND, DH_, and the DL_ gatedrive lines short and wide. To keep the driver impedance low, and for proper adaptive dead-time sensing, the DL_ and DH_ gate traces must be short and wide (50 mils to 100 mils), if the MOSFET is 1in from the controller IC.
- Group the gate-drive components (BST_ diode and capacitor and LDO bypass capacitor, BIAS) together as close as possible to the controller IC. Be aware that gate currents of up to 1A flow from the bootstrap capacitor to BST_, from DH_ to the gate of the external HS switch, and from the LX pin to the inductor. Dimension those traces accordingly.
- Make the DC-DC controller ground connections, as shown in the MAX20094 EV kit component placement guide (see <u>Figure 8</u>). This diagram can be viewed as having two separate ground planes: power ground, where all the high-power components go, and an analog ground plane for sensitive analog components. The analog ground plane and power ground plane must meet only at a single point directly under the IC.
- Connect the output power planes directly to the output filter capacitor's positive and negative terminals with multiple vias, and place the entire DC-DC converter circuit as close as possible to the load.




Figure 8. MAX20094 EV Kit Component Placement Guide/PCB Layout

Ordering Information

PART	TEMP RANGE	PIN-PACKAGE	f _{SW}	V _{OUT}	BUB_UVLO
MAX20094ATIA/VY+	-40°C to +125°C	28 (SW) TQFN-EP*	2.2MHz	6.2V	On
MAX20094ATIB/VY+	-40°C to +125°C	28 (SW) TQFN-EP*	2.2MHz	6.5V	On
MAX20094ATIC/VY+	-40°C to +125°C	28 (SW) TQFN-EP*	2.2MHz	6.8V	On
MAX20094ATID/VY+	-40°C to +125°C	28 (SW) TQFN-EP*	2.2MHz	7.1V	On
MAX20095ATIA/VY+	-40°C to +125°C	28 (SW) TQFN-EP*	2.2MHz	5.5V	On
MAX20095ATIB/VY+	-40°C to +125°C	28 (SW) TQFN-EP*	2.2MHz	8V	On
MAX20095ATIC/VY+	-40°C to +125°C	28 (SW) TQFN-EP*	2.2MHz	9V	On
MAX20095ATID/VY+	-40°C to +125°C	28 (SW) TQFN-EP*	2.2MHz	10V	On
MAX20095ATIE/VY+	-40°C to +125°C	28 (SW) TQFN-EP*	2.2MHz	12V	On

Note: Contact factory for 420kHz f_{SW} on boost.

/V denotes an automotive qualified part.

⁺Denotes a lead(Pb)-free/RoHS-compliant package. (SW) = Side-wettable package.

^{*}EP = Exposed pad.

MAX20094/MAX20095

Backup Battery Charger and Boost Controller

Revision History

REVISION NUMBER	REVISION DATE	DESCRIPTION	PAGES CHANGED
0	7/17	Initial release	_
1	7/17	Updated min and max numbers for Boost Mode Fixed-Output Voltage (V _{SUP2}), deleted Boost Mode Fixed-Output Voltage Accuracy row in <i>Electrical Characteristics</i> ; updated Reset address in <i>CHIP_ID</i> (0x00) register table; removed future product status from MAX20095ATIA/VY+ in <i>Ordering Information</i>	4, 20, 30
2	5/18	Changed package outline number (from 21-100041 to 21-100130) and land pattern number (from 90-0025 to 90-0027), as well as thermal resistances in the <u>Package Information</u> table; removed future product status from MAX20095ATIB/VY+, MAX20095ATIC/VY+, MAX20095ATID/VY+, and MAX20095ATIE/VY+ in the <u>Ordering Information</u> table	3, 30
3	7/19	Updated Simplified Block Diagram, Pin Description, Detailed Description, I2C User Command and Register Map, and Ordering Information	2, 11, 16, 17, 20, 24, 26, 27, 30

For pricing, delivery, and ordering information, please contact Maxim Direct at 1-888-629-4642, or visit Maxim Integrated's website at www.maximintegrated.com.

Maxim Integrated cannot assume responsibility for use of any circuitry other than circuitry entirely embodied in a Maxim Integrated product. No circuit patent licenses are implied. Maxim Integrated reserves the right to change the circuitry and specifications without notice at any time. The parametric values (min and max limits) shown in the Electrical Characteristics table are guaranteed. Other parametric values quoted in this data sheet are provided for guidance.