General Purpose Pushbutton Switches and Indicators

Series 11/21

Rear Mounted Pushbuttons and Indicators

FEATURES

- 250 VAC/5 A, 220 VDC/0.1 A, 24 VDC/2 A snap action 42 VAC/0.1 A, 42 VDC/0.1 A low-level
- Minimum depth: Series 11: 1.08" Series 21: 0.944"
- Mounts in panels to 0.157 inch thick
- Choice of front panel mounting nut
- 5-million operations, low level
- Front panel replaceable lens and lamp

Reference	
International Approvals	page 35
Oil & watertight versions	page 52
Accessories	page 166
Lamps	page 152
Technical Information	page 161

To order: first select switch or indicator desired, indicating contact and terminal type when applicable. Then order lens and illumination separately.

Series 11

Lighted Pushbuttons & Indicators

(Order lens, lamp, and front mounting nut separately)

Switch Element	Momentary	Maintained				
	Round	Round				
Snap Action						
1-pole Form Z	11-131.8 🗆 🗆	11-271.8 🗆 🗆				
2-pole Form Z	11-132.8 🗆 5	11-272.8 5				
3-pole Form Z	11-133.8 🗆 5	11-273.8 🗆 5				
4-pole Form z	11-134.8 🗆 5	11-274.8 🗆 5				
Low Level						
1 N.O. contact	11-435.836	11-475.836				
1 N.C. contact	11-436.836	11-476.836				
2 N.O. contacts	11-431.836	11-471.836				
2 N.C. contacts	11-432.836	11-472.836				
1 N.O., 1 N.C. contact	11-433.836	11-473.836				
ndicator						
Solder connection	11-030.	805				
Length to match low level. Universal terminations	11-031.806					

Select contact and terminal type where applicable

1st digit is always 8 (Case color is gray)

Contact material (2nd digit): 1 = Silver, 2 = Gold over silver

Terminal type (3rd digit): 2 = 0.110" Q.C., 5 = Solder





Series 21 pushbutton snap action



Series 21 pushbutton low level



Series 11 pushbutton snap action

Lenses

☐ Add color digit

Description	Round	0	1	2	3	4	5	6	7	8	9
Lens, with diffuser (lamp)	11-931. 🗆	1		1		1	1	1			1
Lens, no diffuser (LED)	11-932. 🗆			1		1	1	1	1		

0 = Black, 1 = Solar Black, 2 = Red, 3 = Orange, 4 = Yellow, 5 = Green, 6 = Blue 7 = Clear, 8 = Gray, 9 = White. Black and Gray are opaque.

Mounting Nuts







Description	Part Number			
Rear mounting nut (included with switch)				
Front mounting nut required (not included)				
A. Knurled, open face, bright chrome, ø 14 mm	11-935			
B. Knurled, flat face, bright chrome, ø 14 mm	11-936			
C. Knurled, conical face, bright chrome, ø 16 mm	11-937			