





5S Breakers and Accessories

5SX2 and 5SX5 Circuit Breakers (1, 2, 3 and 4 pole)




5SX6 Circuit Breakers (1, 2, 3 and 4 pole)




13

Industrial Components

5SX9 auxiliary contact 5SX9 short circuit alarm contact for mounting to 5SX2, 5SX5



5SX9 auxiliary contact 5SX9 short circuit alarm contact 5SX9 shunt strip for mounting to 5SX6




Note: All Dimensions shown in millimeters. For reference purposes only. Not to be used for design or construction purposes.




5ST Feeder Bus Accessories


Single Phase, 5ST2142 (12 Pole), 5ST2151 (56 Pole)




Single Phase, Double Pole, 5ST2143 (12 Pole), 5ST2153 (56 Pole)




Three Phase, 5ST2144 (12 Pole), 5ST2153 (56 Pole)



5ST2166 Line Side Feeder Bus Feeder Lug (single phase)



5ST2167 Line Side Feeder Bus Feeder Lug (three phase)



Note: All Dimensions shown in inches (millimeters). For reference purposes only. Not to be used for design or construction purposes.

13 Industrial Components