

GLOW™

Light + Handle for your 30oz tumbler



- Light your drinking adventure in style.
- 3 Lighting Modes (220 Task Light, 130 Lantern, Both Lights Combined)
- No more spills & drops, Just grab and go!

LIGHTING FEATURES



TASK LIGHT

220 Lumen HIGH - 3 hours
22 Lumen LOW - 15 hours



LANTERN

130 Lumen HIGH - 3 hours
13 Lumen LOW - 20 hours



COMBINED

Light up everything for 2 hours

FEATURES

- Ergonomic Handle for your 30oz Tumbler
- 3 Lighting Modes (220 Task Light, 130 Lantern, Both Lights Combined)
- Fully dimmable
- Light power memory setting
- Direct-to-lantern light feature
- Rubberized non-slip grip
- Water and impact-resistant
- Powered by 3 AAA batteries (included)

LIGHTING INSTRUCTIONS

- Press button 1x to activate task light (top light)
- Press 2x to activate lantern ring
- Press 3x to activate both
- Press 4x to turn OFF

DIMMABLE BEAM

Each light mode is fully dimmable. Hold button for 1.5 seconds to activate dimming function. C•O•B Task light, lantern are both dimmable.

- Light will dim from 100% to 10% over 3 seconds
- Light will flash quickly when it reaches 10% or 100% to indicate it has reached the lowest or highest light output
- Release button at any time to achieve desired brightness
- Light will continue to dim/brighten between 100% and 10% until button is released

MEMORY POWER SETTING

GLOW is equipped with memory settings for each light mode. To program memory settings, start in the OFF position. Task light and lantern both have this feature.

- Double-tap the button to activate Memory Power Setting. Task light (top) will activate
- Follow Dimming Instructions to adjust light to desired brightness
- Press button again to move to next setting. Light will cycle through each light mode sequentially
- Set each light mode at desired brightness level
- If 100% brightness is desired amongst light modes, simply press button to move to the next mode
- Press again to turn OFF

To reprogram, simply repeat the previous steps.

DIRECT-TO-LANTERN

Press and hold the button from OFF to activate lantern directly. Press button again to turn OFF.

BATTERY INSTALLATION

1. To open battery compartment, remove battery cover located on the bottom of the handle by sliding it Out.
2. Remove battery cartridge.
3. Remove old batteries and dispose of properly. Insert 3 new AAA alkaline batteries, making sure that the negative end (-) is facing the spring. Polarity markings are indicated on the battery tray to assist in proper polarity positions.
4. Reinsert battery cartridge into flashlight. Make sure battery cartridge is facing the correct direction.
5. Reattach the cover by sliding it back On.



Replace with fresh batteries by matching polarity with markings on the battery tray

INTERNATIONAL PATENTS PENDING