

# Complete units: Push-buttons $\phi$ 22MM

 Technical Info (p. 103)

## ► SPRING RETURN - NON-ILLUMINATED


### FLUSH

Chrome Bezel  
Part Number

Black Bezel  
Part Number





L21AA01-1E01



#### WITH SINGLE POSITION CLIP


● Red	NC	L21AA01-1E01	L22AA01-1E01
● Green	NO	L21AA02-1E10	L22AA02-1E10
● Black	NO	L21AA03-1E10	L22AA03-1E10
● Yellow	NO	L21AA04-1E10	L22AA04-1E10
○ White	NO	L21AA05-1E10	L22AA05-1E10
● Blue	NO	L21AA06-1E10	L22AA06-1E10

#### WITH INTERNATIONAL SYMBOLS

	Red	NC	L21AA81-1E01	L22AA81-1E01
	Green	NO	L21AA82-1E10	L22AA82-1E10



L22AA02-3E10



#### WITH THREE POSITION CLIP


● Red	NC	L21AA01-3E01	L22AA01-3E01
● Green	NO	L21AA02-3E10	L22AA02-3E10
● Black	NC	L21AA03-3E01	L22AA03-3E01
● Black	NO	L21AA03-3E10	L22AA03-3E10
● Yellow	NO	L21AA04-3E10	L22AA04-3E10
○ White	NO	L21AA05-3E10	L22AA05-3E10
● Blue	NO	L21AA06-3E10	L22AA06-3E10

● Red	NO + NC	L21AA01-3E11	L22AA01-3E11
● Green	NO + NC	L21AA02-3E11	L22AA02-3E11
● Black	NO + NC	L21AA03-3E11	L22AA03-3E11
● Yellow	NO + NC	L21AA04-3E11	L22AA04-3E11
○ White	NO + NC	L21AA05-3E11	L22AA05-3E11
● Blue	NO + NC	L21AA06-3E11	L22AA06-3E11

### PROJECTING



L21AB04-3E11



#### WITH SINGLE POSITION CLIP

● Red	NC	L21AB01-1E01	L22AB01-1E01
● Green	NO	L21AB02-1E10	L22AB02-1E10
● Black	NO	L21AB03-1E10	L22AB03-1E10
● Yellow	NO	L21AB04-1E10	L22AB04-1E10
○ White	NO	L21AB05-1E10	L22AB05-1E10
● Blue	NO	L21AB06-1E10	L22AB06-1E10

#### WITH THREE POSITION CLIP

● Red	NO + NC	L21AB01-3E11	L22AB01-3E11
● Green	NO + NC	L21AB02-3E11	L22AB02-3E11
● Black	NO + NC	L21AB03-3E11	L22AB03-3E11
● Yellow	NO + NC	L21AB04-3E11	L22AB04-3E11
○ White	NO + NC	L21AB05-3E11	L22AB05-3E11
● Blue	NO + NC	L21AB06-3E11	L22AB06-3E11

#### WITH INTERNATIONAL SYMBOL

	Red	NC	L21AB01B-1E01	L22AB31A70-1E01
---	-----	----	---------------	-----------------