



Speakon®

NLT8MP Chassis Connector

Assembly Instructions



Ⓐ NLT8MP is equipped with spacer by default.



Ⓑ In case of spade termination 6.3 x 0.8 mm (FASTON®) spacer must be removed.

NEUTRIK AG

Liechtenstein
Tel.: +423/237 24 24
Fax: +423/232 53 93
www.neutrik.com

NEUTRIK Zürich AG

Switzerland
Tel.: +41 44/736 5010
Fax: +41 44/736 5011

NEUTRIK (UK) Ltd.

Great Britain
Tel.: +44 1983/811 441
Fax: +44 1983/811 439

NEUTRIK USA INC.

USA
Tel.: +1 732/901 9488
Fax: +1 732/901 9608

NEUTRIK Tokyo Ltd.

Japan
Tel.: +81 3/3663 4733
Fax: +81 3/3663 4796

NEUTRIK France

France
Tel.: +33 1/4131 6750
Fax: +33 1/4131 0511

NEUTRIK Vertriebs GmbH

Germany/Netherlands/Austria
Tel.: +49 8131/28 08 90
Fax: +49 8131/28 08-30

Draft. Nr.: BDA 174-0 / 3102M431
Update: 16.02.2006



NEUTRIK®
CONNECTING THE WORLD