# Quad Pak AC Output Module

#### Features

- Sontains four, single channel I/O circuits.
- Each module can be divided into two pairs with each pair sharing a common connection.
- used for controlling or switching AC loads.
- Provides up to 4,000 Vrms of optical isolation between the field devices and the control logic.
- Y Features zero voltage turn-on and zero current turn-off

### Description

Quad Pak modules contain the equivalent of four, single channel I/O circuits in a single high-density package. Each Quad Pak module can be divided into two pairs with each pair sharing a common connection. The Quad Pak modules are designed to plug into the Quad Pak high-density I/O mounting racks only and cannot be plugged into single channel racks. Quad Pak modules are designed to work with a 5 VDC logic voltage only and can be used with Optomux, Pamux, and Mistic protocol brain boards and mounting racks as well as racks using a direct cable connection to a computer.

AC output modules are used for controlling or switching AC loads. Each module provides up to 4,000 Vrms of optical isolation between the field devices and the control logic. The Quad Pak AC output module features zero voltage turn-on and zero current turn-off.

Typical uses and applications for AC output modules include switching the following loads:

- Relays
- Solenoids and Contactors
- Motor Starters
- Heaters
- Lamps or Indicators



OAC5Q

# **OPTO 22** Quad Pak AC Output Module

#### **Part Numbers**

Part	Description	
OAC5Q	4-Channel AC Output 12-280 VAC, 5 VDC Logic	

Opto 22 • 43044 Business Park Drive • Temecula, CA 92590-3614 • www.opto22.com

SALES 800-321-6786 • 951-695-3000 • FAX 951-695-3095 • sales@opto22.com • SUPPORT 800-835-6786 • 951-695-3080 • FAX 951-695-3017 • support@opto22.com © 2012 Opto 22. All rights reserved. Dimensions and specifications are subject to change. Brand or product names used herein are trademarks or registered trademarks of their respective companies or organizations.

DATA SHEET Form 486-120120

PAGE

1

## **Specifications**

Line Voltage-Nominal	120/240 VAC	
Operating Voltage Range	12–280 VAC	
Current Rating @ 20° C Ambient @ 45° C Ambient	3 amps 2 amps	
One Cycle Surge	80 amps	
Logic Voltage–Nominal	5 VDC	
Logic Voltage Range (Vcc)	4–8 VDC	
Logic Pickup Voltage	4.0 VDC	
Logic Dropout Voltage	2.3 VDC	
Logic Input Current @ Nominal Logic Voltage (lout in Schematic Diagram)	12 mA	
Control Resistance (Rc in Sche- matic Diagram)	220 ohms	
Peak Repetitve Voltage	500 volts	
Operating Ambient Temperature	-30 to 70 °C	
Isolation Input-to-Output	4,000 Vrms	
Minimum Load Current	20 milliamps	
Operating Frequency	25–65 Hz	
Turn-on Time	1/2 cycle maximum-zero voltage	
Turn-off Time	1/2 cycle maximum-zero current	
DV/DT-Off-state	snubbed for rated 0.5 power factor load	
Output VOltage Drop Maximum Peak	1.6 volts	
Off-state Leakage @ Nominal Voltage-60Hz	5 milliamps, ms	

Quad Pak AC Output Module **OPTO 22** 


Form 486-120120 DATA SHEET PAGE

2


Opto 22 • 43044 Business Park Drive • Temecula, CA 92590-3614 • www.opto22.com SALES 800-321-6786 • 951-695-3000 • FAX 951-695-3095 • sales@opto22.com • SUPPORT 800-835-6786 • 951-695-3080 • FAX 951-695-3017 • support@opto22.com © 2012 Opto 22. All rights reserved. Dimensions and specifications are subject to change. Brand or product names used herein are trademarks or registered trademarks of their respective companies or organizations.

# **Quad Pak AC Output Module**

**Dimensions** 



## **Schematics**



**Quad Pak AC Output Module** 

OPTO

N N


Opto 22 • 43044 Business Park Drive • Temecula, CA 92590-3614 • www.opto22.com SALES 800-321-6786 • 951-695-3000 • FAX 951-695-3095 • sales@opto22.com • SUPPORT 800-835-6786 • 951-695-3080 • FAX 951-695-3017 • support@opto22.com © 2012 Opto 22. All rights reserved. Dimensions and specifications are subject to change. Brand or product names used herein are trademarks or registered trademarks of their respective companies or organizations.

3



DATA SHEET Form 486-120120

> PAGE 4



Opto 22 • 43044 Business Park Drive • Temecula, CA 92590-3614 • www.opto22.com SALES 800-321-6786 • 951-695-3000 • FAX 951-695-3095 • sales@opto22.com • SUPPORT 800-835-6786 • 951-695-3080 • FAX 951-695-3017 • support@opto22.com © 2012 Opto 22. All rights reserved. Dimensions and specifications are subject to change. Brand or product names used herein are trademarks or registered trademarks of their respective companies or organizations.

# Quad Pak AC Output Module

## **Products**

Opto 22 develops and manufactures reliable, flexible, easy-touse hardware and software products for industrial automation, energy management, remote monitoring, and data acquisition applications.

#### **OptoEMU Energy Management System**

The easy-to-use OptoEMU Sensor monitors electrical energy use in your facility and delivers detailed, real-time data you can see and analyze. The Sensor can monitor energy data from pulsing meters, electrical panels or subpanels, and equipment. View energy data online using a software service or incorporate the data into your control system for complete energy management.

#### **SNAP PAC System**

Designed to simplify the typically complex process of selecting and applying an automation system, the SNAP PAC System consists of four integrated components:

- SNAP PAC controllers
- PAC Project<sup>™</sup> Software Suite
- SNAP PAC brains
- SNAP I/O<sup>™</sup>

#### **SNAP PAC Controllers**

Programmable automation controllers (PACs) are multifunctional, modular controllers based on open standards.

Opto 22 has been manufacturing PACs for over two decades. The standalone SNAP PAC S-series and the rack-mounted SNAP PAC R-series both handle a wide range of digital, analog, and serial functions for data collection, remote monitoring, process control, and discrete and hybrid manufacturing.

SNAP PACs are based on open Ethernet and Internet Protocol (IP) standards, so you can build or extend a system easily, without the expense and limitations of proprietary networks and protocols.

#### PAC Project Software Suite

Opto 22's PAC Project Software Suite provides full-featured, cost-effective control programming, HMI (human machine interface) development and runtime, OPC server, and database connectivity software for your SNAP PAC System.

Control programming includes both easy-to-learn flowcharts and optional scripting. Commands are in plain English; variables and I/O point names are fully descriptive.

PAC Project Basic offers control and HMI tools and is free for download on our website, www.opto22.com. PAC Project Professional, available for separate purchase, adds OptoOPCServer, OptoDataLink, options for controller redundancy or segmented networking, and support for legacy Opto 22 serial  $mistic^{m}$  I/O units.

#### **SNAP PAC Brains**

While SNAP PAC controllers provide central control and data distribution, SNAP PAC brains provide distributed intelligence for I/O processing and communications. Brains offer analog, digital, and serial functions, including thermocouple linearization; PID loop control; and optional high-speed digital counting (up to 20 kHz), quadrature counting, TPO, and pulse generation and measurement.

#### SNAP I/O

I/O provides the local connection to sensors and equipment. Opto 22 SNAP I/O offers 1 to 32 points of reliable I/O per module, depending on the type of module and your needs. Analog, digital, and serial modules are all mixed on the same mounting rack and controlled by the same processor (SNAP PAC brain or rack-mounted controller).

# Quality

Founded in 1974, Opto 22 has established a worldwide reputation for high-quality products. All are made in the U.S.A. at our manufacturing facility in Temecula, California. Because we do no statistical testing and each part is tested twice before leaving our factory, we can guarantee most solid-state relays and optically isolated I/O modules for life.

# **Free Product Support**

Opto 22's California-based Product Support Group offers free, comprehensive technical support for Opto 22 products. Our staff of support engineers represents decades of training and experience. Support is available in English and Spanish by phone or email, Monday–Friday, 7 a.m. to 5 p.m. PST.

Additional support is always available on our website: how-to videos, OptoKnowledgeBase, self-training guide, troubleshooting and user's guides, and OptoForums.

In addition, hands-on training is available for free at our Temecula, California headquarters, and you can register online.

# **Purchasing Opto 22 Products**

Opto 22 products are sold directly and through a worldwide network of distributors, partners, and system integrators. For more information, contact Opto 22 headquarters at 800-321-6786 or 951-695-3000, or visit our website at www.opto22.com.

# www.opto22.com

www.opto22.com • Opto 22 • 43044 Business Park Drive • Temecula, CA 92590-3614 • Form 1335-110907 SALES 800-321-6786 • 951-695-3000 • FAX 951-695-3005 • sales@opto22.com • SUPPORT 800-835-6786 • 951-695-3080 • FAX 951-695-3017 • support@opto22.com © 2012 Opto 22. All rights reserved. Dimensions and specifications are subject to change. Brand or product names used herein are trademarks or registered trademarks of their respective companies or organizations.