

---

**BATTERY REPLACEMENT FOR AEMC MODELS  
1060, 5050, 5060, 5070, 6505, 4630, 6470, 6471 & 6472**

---

The battery should only be replaced by Chauvin Arnoux<sup>®</sup> Inc. d.b.a AEMC<sup>®</sup> Instruments or an approved technician.

**NOTE:** Replacing the battery causes data to be lost from the instruments memory. It is recommended to download the memory for Models 1060, 5060 and 5070 before changing the batteries.

#### Disassembling of the Front Plate Assembly and Protective Cover

To access the battery compartment and service connector:

1. Unscrew the 4 screws accessible from the bottom of the instrument.



2. Remove the instrument from the case. Be careful of the seal ring around the front plate.
3. Unscrew the 2 screws of the battery cover and remove the cover. Carefully lift the battery out and place next to the battery compartment.

