Miniature Regulator ARJ1020F Series

- Compact and lightweight (16 g)
- Low cracking pressure 0.02 MPa Standard model equipped with backflow function



ARJ1020F-M5-04

ARJ1020F-M5-06



Symbol

Note) A standard model is equipped with a backflow function. A main valve opens when the inlet pressure is released, and then an outlet pressure backflows into the inlet side.

Standard Specifications

Model		ARJ1020F		
Port	IN side	M5 (Male thread)		
size	OUT side (Applicable tubing O.D.)	ø4	ø6	
Fluid		Air		
Proof pressure		1.2 MPa		
Maximum operating pressure		0.8 MPa		
		Standard: 0.1 to 0.7 MPa		
Regulatii	ng pressure range	0.2 MPa setting 0.05 to 0.2 MPa		
Ambient	and fluid temperature	-5 to 60°C (No freezing)		
Construc	tion	Relieving type		
Weight (kg)		0.015	0.016	
Cracking pressure (Valve)		0.02 MPa		
Max. effective area (OUT→IN)		1.8 mm ²		
Applicable tubing material Note)		Nylon, Soft nylon, Polyurethane		

Note) Be sure to note the maximum operating pressure for soft nylon and polyurethane. (Refer to Best Pneumatics No. 7.)

Accessory (Option)/Part No.

SMC

Description	Part no.	
Manifold base	ARJM10-4, -6, -10	

How to Order



Miniature Regulator **ARJ1020F** Series

2.

2.

Construction/Dimensions





F

Component Parts

Dimensions

No.	Description	Material	Note
1	Body	PBT	
2	Valve guide	Brass	Electroless nickel plated
3	Piston	Polyacetal	
4	Bonnet	Brass	Electroless nickel plated
5	Knob	Brass	Electroless nickel plated
6	Adjusting spring	Steel wire	Zinc chromated
7	Valve	Brass	Rubber lining
10	Nipple	Brass	Electroless nickel plated

Replacement Parts

No.	Description	Material	Part no.		
7	Valve	Brass, HNBR	13434-30#1		
8	Gasket	Stainless steel	P233014-04		
		NBR			
9	Spring	Stainless steel	134313		

Panel mounting hole

Max. 2.5t

* When replacing valves and springs, remove nipple first. Note that adhesive is applied to the nipple portion.

Dimensions										
Model	Α	В	С	D	E	F	G	н	J	К
ARJ1020F-M5-04	21	10.4	4	MEYOO	6	10.6	25	15.5	50	17.0
ARJ1020F-M5-06	22	12.8	6	0.0 X CIVI	0	flats: 10)	3.5	15.5	50	17.2

Manifold Base (Option)/Dimensions

66.5 33 20

hole)







Manifold base part no.	Stations	A dimension	B dimension
ARJM10-4	4	90	82
ARJM10-6	6	130	122
ARJM10-10	10	210	202

Be sure to read this before handling the products. Refer to back page 50 for Safety Instructions and pages 387 to 391 for Precautions on every	
series.	55
Piping AR)	X
∆Warning AMI	R
I. To connect the IN side, hold the valve guide at its wrench flats (opposite side 10) and tighten it at the recommended	N
torque of 1.5 to 2 N·m.	P
area other than the specified portion may result in a malfunction.	A
2. While piping to products or operating the knob, ensure that an excess	
bending moment should not be applied to a product, because it may result in damage	I
VE)	X
Mounting/Adjustment SRI	Η
AWarning SRI	P
pressure that is indicated on the inlet and the outlet pressure gauges. Turning	F
internal parts.	
∆Caution IC	
After the adjustment, engage the lock.	H
damage the knob or cause the outlet pressure to fluctuate.	X
<pre><lock method="" operating=""> Loosen the lock nut to unlock it, and</lock></pre>	D
tighten it to lock it. 2. This product can be used as a check	1
regulator by installing it between vBA solenoid valve and actuator.	т
AP10	0

Miniature Regulator ARJ210 Series

- Lightweight body made of aluminum (60 g)
- Two types of piping connections provided for the IN side: 1/8 (male thread) and M5 (female thread)



AB.1210-M5

ARJ210-M5BG

Symbol



Standard Specifications

Model		ARJ210-M5		
Dout oine	IN side	1/8 (Male thread), M5 x 0.8 (Female thread)		
Port size	OUT side	M5 x 0.8 (Female thread 2 pcs.)		
Fluid		Air		
Proof pressure		1.2 MPa		
Maximum operating pressure		0.8 MPa		
Regulating pressure range		Standard: 0.2 to 0.7 MPa		
		0.2 MPa setting 0.05 to 0.2 MPa		
Pressure gauge port size		M5 x 0.8 (Female thread)		
Ambient and fluid temperature		-5 to 60°C (No freezing)		
Construction		Relieving type		
Weight (kg)		0.06		

Accessory (Option)/Part No.

Bracket	134856			
Pressure gauge Note)	G27-10-R1			
Note) When ordering the pressure gauge, a socket assembly (134828A) is required.				

When installing a pressure gauge, the socket assembly must be fixed and installed to prevent the thread from breaking. 0.2 MPa specification is not available for G27.



A main valve opens when the inlet pressure is released, and then an outlet pressure backflows into the inlet side.

X209 is a product with pressure gauge (G27-10-M-X202). The symbol "G" for accessory is not necessary.

Flow Rate

Characteristics (Representative values)



SMC





Miniature Regulator **ARJ210** Series

Construction/Dimensions



No.	Description	Material	Note
1	Body	Aluminum alloy	Black anodized
2	Valve guide	Brass	Electroless nickel plated
3	Piston	POM	
4	Adjusting screw	Iron	Nickel plated
5	Adjusting spring	Steel wire	Zinc chromated

A Precautions



Selection

∆Warning

- This product cannot be used as a check regulator by installing it between solenoid valve and actuator. Doing so could lead to equipment damage.
- 2. When connecting a pipe to the IN side, hold the valve guide at its wrench flats (opposite side 11), and when connecting to the OUT side, hold the body at its hexagon portion and tighten it to the recommended torque. (M5: 1.5 to 2 N·m, R 1/8: 7 to 9 N·m) Excessive torque or holding it other than at the specified area could lead to equipment damage.
- While piping to products or operating the knob, ensure that an excessbending moment should not be applied to a product, because it may result in damage.

Mounting/Adjustment

∆Warning

 Set up the regulator while verifying the pressure that is indicated on the inlet and the outlet pressure gauges. Turning the knob excessively could damage the internal parts.

∆Caution

 Release the lock to adjust the pressure. After the adjustment, engage the lock. Failure to observe this procedure could damage the knob or cause the outlet pressure to fluctuate.
 <Lock operating method>
 Loosen the lock nut to unlock it, and tighten it to lock it

 This product cannot be used as a check regulator by installing it between solenoid valve and actuator. (Except X209)

 Port with a pressure gauge or a plug can be used as an OUT port.

Maintenance

∆Warning

 Make sure to perform a periodic inspection of the pressure gauge when the miniature regulator is installed between a solenoid valve and an actuator. Sudden pressure changes could happen and the durability of the product could be reduced. Using an electronic type pressure gauge is recommended, depending on the situation.