

The PLM Series continuously measures the voltage of each of the three phases. The PLM Series uses a microcontroller circuit design that senses undervoltage, voltage unbalance, phase loss, and phase reversal. Protection is assured when regenerated voltages are present. Both delta and wye systems can be monitored; no connection to neutral is required.

For more information see:

The output relay is energized and the LED glows green when all voltages are acceptable and the phase sequence

is correct. Under and unbalanced voltages must be sensed for a continuous trip delay period before the relay

de-energizes. Reset is automatic upon correction of the fault condition. The output relay will not energize if a

fault condition is sensed as power is applied. The LED flashes red during the trip delay, then glows red when

Set voltage adjustment knob at the desired operating line voltage for the equipment. This adjustment automatically

sets the undervoltage trip point. Apply power. If the PLM fails to energize, (LED glows red) check wiring of all 3 phases, voltage, and phase sequence. If phase sequence is incorrect, the LED flashes green/red. To correct

this, swap any two line voltage connections at the mounting socket. No further adjustment should be required.

the output de-energizes. The LED flashes green/red if phase reversal is sensed.

Appendix B, page 165, Figure 8 for dimensional drawing. Appendix C, page 168, Figure 13 for connection diagram.

### **Features:**

- Protects against phase loss & reversal; & under & unbalanced voltages
- 8-pin plug-in base
- Adjustable low voltage trip point
- · Factory fixed unbalance & trip delay
- Line voltages 200 to 480VAC in 3 ranges
- Isolated, 10A, SPDT output contacts
- ASME A17.1 rule 210.6
- NEMA MG1 14:30, 14:35
- IEEE C62.41-1991 Level B

Approvals: (E R) @

## **Auxiliary Products:**

- Panel mount kit: P/N: BZ1
- Octal 8-pin socket: P/N: OT08PC
- 3-phase fuse block/disconnect: P/N: FH3P
- **2 Amp fuse:** P/N: P0600-11
- **DIN rail:** P/N: C103PM (AI)

### **Available Models:**

PLM6405	PLM9405
PLM6502	PLM9502
PLM6805	PLM9805
PLM8405	PLM9820
PLM8805	

If desired part number is not listed, please call us to see if it is technically possible to build.

### Order Table:

PLM

Line Voltage

Operation

Field Adjustment:

Line Voltage -6 - 240VAC -8 - 380VAC -9 - 480VAC X Voltage Unbalanced Fixed - Specify - 4-8% in 1% increments

Trip Delay
Fixed - Specify from 2-20s
in 1s increments using

two digits

# Specifications

Phase Reversal & Phase Loss Response Time: Phase R

		neutral			
Operating Voltage:	Model	Adj. Line Voltage Range	Line Voltage Max.		
	240	200-240VAC	270VAC		
	380	360-430VAC	480VAC		
	480	400-480VAC	530VAC		
AC Line Frequency					
Phase Sequence ABC					
Power Consumption					
_		≅ 3W for 380 - 480\	/ units		
Low Voltage & Voltage Unbalance					
Type		Voltage detection v	with delayed trip & automa		
Low Voltage	Tuin		d line veltage		
Low Voltage		Voltage 88 - 92% of adjusted t Voltage Plus 3% of trip vol			
Voltage Unbalance		Unbalance Factory fixed from			
voltage Ulibalatice		9			
Trip Delay		t on Balance0.7% unbalance ty	1		
ттр Бегау		ge Factory fixed from	2 - 208		

Phase Reversal . . . .  $\leq$  200ms Phase Loss . . . .  $\leq$  200ms

......3-phase delta or wye with no connection to


	Phase Loss.	. ≥35% unbalance
	Reset	. Automatic
	Output	
	Type	. Electromechanical relay
	Form	. Isolated, SPDT
	Rating	. 10A resistive @ 240VAC, 277VAC max;
		1/2 Hp @ 240VAC; 1/4 Hp @ 120VAC
	Life	. Mechanical - 1 x 10'; Electrical - 1 x 10°
	Protection	
	Surge	. IEEE C62.41-1991 Level B
	Isolation Voltage	. ≥ 2500V RMS input to output
	Mechanical	
	Mounting*	
C	Dimensions	. 3.2 x 2.39 x 1.78 in. (81.3 x 60.7 x 45.2 mm)
	Environmental	
	Operating / Storage Temperature	40° to 60°C / -40° to 85°C
	Weight	. ≅ 4.4 oz (125 g)
	*CAUTION: Select an octal socket rated for	r 600VAC operation.

# Appendix B - Dimensional Drawings

## FIGURE 1 ≤ 1.21 (30.7)0.75 2.00 (19)(50.8)2.00 (50.8)0.25 (6.35) DIA. 0.25 (6.35)


CT; ESD5; ESDR; FS100; FS200; FS300; KRD3; KRD9; KRDB; KRDI; KRDM; KRDR; KRDS; KRPD; KRPS; KSD1; KSD2; KSD3; KSD4; KSDB; KSDR; KSDS; KSDU; KSPD; KSPS; KSPU; KVM; T2D; TA; TAC1; TAC4; TDU; TDUB; TDUI; TDUS; TL; TMV8000; TS1; TS2; TS4; TS6; TSB; TSD1; TSD2; TSD3; TSD4; TSD6; TSD7; TSDB; TSDR; TSDS; TSS; TSU2000

### FIGURE 2




HLV; HRD3; HRD9; HRDB; HRDI; HRDM; HRDR; HRDS; HRID; HRIS; HRIU; HRPD; HRPS; HRPU; HRV; RS

### FIGURE 3




**HSPZ** 

### FIGURE 4




FA; FS; FSU1000\*; NHPD; NHPS; NHPU; NLF1\*; NLF2\*; PHS\*; PTHF\*; SIR1; SIR2; SLR1\*; SLR2\*; TH1; TH2; THC; THD1; THD2; THD3; THD4; THD7; THDB; THDM; THDS; THS


#### FIGURE 5



**TRDU** 




### FIGURE 6




TRU

## \*If unit is rated @ 1A, see Figure 1 FIGURE 7




ASQU; ASTU; DSQU; DSTU

# FIGURE 8




PLM; PLR; TDB; TDBH; TDBL; TDI; TDIH; TDIL; TDM; TDMB; TDMH; TDML; TDR; TDS; TDSH; TDSL

# FIGURE 9



FS500; PRLB; PRLM; PRLS; TRB; TRM; TRS



#### **FIGURE 11**





FIGURE 12 (38.1)(25.4).94 (23.88)0 .19 (4.83) (12.70)

FS100; FS400

inches (millimeters)


# Appendix C - Connection Diagrams

### FIGURE 1 - FSU1000 Series



S1 = Optional low current switch V = Voltage L = Load

#### FIGURE 2 - FS100 Series



B = Black Wire

FIGURE 3 - FS100 Series




FIGURE 4 - FS200 Series




FIGURE 5 - FS300 Series





FIGURE 6 - FS400 Series



R = Red Wire B = Black Wire W= White Wire

L2 2 3 0 L1

FIGURE 7 - AF Series

V = Voltage


L = Load

V = Voltage


FIGURE 8 - FS500 Series

FIGURE 11 - DLMU Series

### FIGURE 9 - SC3/SC4 Series



for SC3, terminal 6 & load L4 are eliminated.



F = Fuses

RS = Optional Remote Reset Switch Relay contacts are isolated.

CAÚTION:

2 amp max fast acting fuses must be installed externally in series with each input. (3)

FIGURE 10 - WVM Series

NO = Normally Open NC = Normally Closed


# ! = Select alarm contact connection as N.O. or N.C. when ordering; N.O. Shown.

L1, L2, L3 = Line Voltage Input NO = Normally Open Contact NC = Normally Closed Contact C = Common, Transfer Contact

CAUTION: 2 amp max. fast acting fuses are recommended to protect the equipment's wiring. They are not required to protect the DLMU.

 $\Theta$ 


# FIGURE 12 - HLMU Series



NO = Normally Open Contact NC = Normally Closed Contact C = Common, Transfer Contact

CAUTION: 2 amp max. fast acting fuses are recommended to protect the equipment's wiring. They are not required to protect the HLMU.


# FIGURE 13 -



F = Fuses  $\emptyset$ A = Phase A = L1  $\emptyset$ B = Phase B = L2  $\emptyset$ C = Phase C = L3

NO = Normally Open NC = Normally Closed 2A fast acting fuses recommended for safety (not

required) Relay contacts are isolated.



L1 = Phase A

L2 = Phase B

L3 = Phase C

NO = Normally Open NC = Normally Closed

C = Common, Transfer Contact

Relay contacts are isolated. F = 2A Fast acting fuses are recommended,

but not required