

WILMAR[™] Protective Relays – WOF & WUF Series



4 HOLES

Note: Dimensions in inches. Multiply values by 25.4 for dimensions in mm.



PRODUCT SPECIFICATIONS

Part Number	WOF/WUF
Nominal Voltage (±20%)	120, 230, 380 and 460 volts
Nonimal Frequencies	50, 60 and 400 Hz.
Trip Point	Screwdriver adjustable. Adjustment range in accordance with ordering information.
Operating Temperature	-20°C to +65°C
Differential	The frequency pitch-up to drop-out differential is .5% max
Voltage Drift	\pm .05% maximum frequency error for input voltage variation of $\pm 10\%$
Time Delay	See Time versus Frequency curves
Surge Withstand Capability	In compliance with C37.90B ANSI/IEEE
Output Contacts	One set N.O., one set N.C.
Contact Ratings	5 amp resistive at 120 VAC or 28VDC

Function: 81 O/U

- ANSI/IEEE C37.90-1978
- UL file No. E58048
- CSA file No. LR61158



(SP

Application:

The output contacts of frequency relays are energized when the frequency exceeds the adjustable set point. Overfrequency and underfrequency relays are available in 50, 60 and 400Hz. Combination over/ underfrequency "band pass" relays are also available. These are energized at rated frequency and deenergized during overfrequency or underfrequency conditions. Frequency Differential relays are energized above the preset frequency. The pick-up and drop-out frequency settings are independently adjustable.



Time Delay

Standard Time Delay

A minimum, fixed inverse time delay is incorporated in all frequency relays to prevent nuisance tripping and is represented by the typical curves shown below.

Adjustable Time Delay

If additional time delay is required, a suffix "T" must be added to the part number. This allows the minimum fixed time delay to be field-adjustable up to 20 seconds

PART NUMBER SELECTION
Sample Part No. WUF-12-5060-T
Туре:
WUF = Underfrequency
WOF = Overfrequency
Input Voltage (VAC)
12 = 120
23 - 230
38 = 380
46 = 460
Frequency Range
4050 = 40-50 HZ
5060 = 50-60 HZ
6070 = 60-70 HZ
3540 = 350-400 HZ
4045 = 400-450 HZ (overfrequency only)
Time Delay Options
blank = Per Time Curve
T = Adjustable
Consult factory for additional models.

Notes:

1. Remove black screws for access to the frequency and the time adjustments.

2. Clockwise rotation of the frequency potentiometer will raise the frequency trip point.

 Clockwise rotation of the time adjustment, option "T" will increase the time for overfrequency relays and dropout time for underfrequency relays.

Tyco Electronics / www.tycoelectronics.com / Factory Direct Technical Support: 800-253-4560, ext. 2023 (U.S., Canada, Mexico) or 805-220-2020, ext. 2023 (International)