# **PLD Development Software Tools Overview**

Atmel tools serve the needs of beginning users as well as more experienced users. Based on the background of the user, we can make recommendations on the most cost-effective solution (see Table 1). If you have any questions regarding which package is best suited to a particular set of needs, please contact the Atmel PLD Technical Support Hotline at (408) 436-4333 or e-mail to pld@atmel.com.

This document outlines general system configurations required to use the various systems, details each package including ordering information, and includes a section with suggested systems for various types of users.

Atmel offers several levels of systems to meet the various needs of our customers. The systems are described on the following pages, along with a brief description of their function. For further information, contact your local Atmel sales representative, or the Atmel PLD Hotline at (408) 436-4333, or PLD e-mail at pld@atmel.com.



CMOS PLD
Development
Software
Support
Overview







Table 1. PLD Software System Recommendations

| User   | Experience   | Recommended System                          |
|--|--|---|
| New PLD User   | No prior PLD experience. Wants basic support for PAL-type and V-Series devices and is willing to do manual pin assignment.   | ATDS1000PC (Atmel-WINCUPL)                  |
| PAL-type (SPLD)<br>Device User                                     | Knows ABEL, CUPL, or PALASM, and is familiar with 22V10 design. Wants to move up in density, and wants automatic fitting to reduce need to learn detailed internals of each device.                                | ATDS1500PC (ProChip Designer <sup>™</sup> ) |
| Complex PLD User<br>Microcontroller<br>Designer or TTL<br>Designer | Uses complex PLDs from Altera, XILINX, or Lattice. Wants state-of-the-art tools for Atmel's CPLDs to take advantage of their speed and density. Wants schematic capture, VHDL entry support and device simulation. | ATDS1500PC (ProChip Designer <sup>™</sup> ) |

| Product    | Description                   |
|------------|-------------------------------|
| ATDS1000PC | Atmel-WINCUPL <sup>™</sup>    |
| ATDS1500PC | ProChip Designer <sup>™</sup> |

Table 2. PLD System Configuration Requirements

|                  |                   | ATDS1000PC (Atmel-WINCUPL)                        | ATDS1500PC (ProChip Designer)    |
|------------------|-------------------|---|----------------------------------|
| Platform         |                   | Pentium <sup>®</sup>                              | Pentium II®                      |
| Operating System |                   | Windows 95 <sup>®</sup> , Windows 98 <sup>®</sup> | Windows 95/98/NT <sup>®(1)</sup> |
| Display Adaptor  |                   | CGA, EGA, VGA or SVGA                             | VGA/SVGA                         |
| System Memory    |                   | 8 MB  | 64 MB                            |
| Hard Disk        | Space Recommended | 10 MB   | 60 MB                            |
| Mouse            |                   | Not required                                      | 2/3-button mouse                 |

Notes: 1. ProChip Designer Trial Edition has known problems with WinME® and Windows 2000® operating systems. Although we have not verified operation of ProChip Designer permanent license on WinME and Windows 2000, some users have reported successful use.



# **Atmel Headquarters**

Corporate Headquarters 2325 Orchard Parkway San Jose, CA 95131 TEL (408) 441-0311 FAX (408) 487-2600

# Europe

Atmel SarL Route des Arsenaux 41 Casa Postale 80 CH-1705 Fribourg Switzerland TEL (41) 26-426-5555 FAX (41) 26-426-5500

#### Asia

Atmel Asia, Ltd. Room 1219 Chinachem Golden Plaza 77 Mody Road Tsimhatsui East Kowloon Hong Kong TEL (852) 2721-9778 FAX (852) 2722-1369

#### Japan

Atmel Japan K.K. 9F, Tonetsu Shinkawa Bldg. 1-24-8 Shinkawa Chuo-ku, Tokyo 104-0033 Japan TEL (81) 3-3523-3551 FAX (81) 3-3523-7581

## **Atmel Product Operations**

Atmel Colorado Springs 1150 E. Cheyenne Mtn. Blvd. Colorado Springs, CO 80906 TEL (719) 576-3300 FAX (719) 540-1759

#### Atmel Grenoble

Avenue de Rochepleine BP 123 38521 Saint-Egreve Cedex, France TEL (33) 4-7658-3000 FAX (33) 4-7658-3480

### Atmel Heilbronn

Theresienstrasse 2 POB 3535 D-74025 Heilbronn, Germany TEL (49) 71 31 67 25 94 FAX (49) 71 31 67 24 23

#### **Atmel Nantes**

La Chantrerie BP 70602 44306 Nantes Cedex 3, France TEL (33) 0 2 40 18 18 18 FAX (33) 0 2 40 18 19 60

#### Atmel Rousset

Zone Industrielle 13106 Rousset Cedex, France TEL (33) 4-4253-6000 FAX (33) 4-4253-6001

## **Atmel Smart Card ICs**

Scottish Enterprise Technology Park East Kilbride, Scotland G75 0QR TEL (44) 1355-357-000 FAX (44) 1355-242-743

e-mail literature@atmel.com

Web Site http://www.atmel.com

*BBS* 1-(408) 436-4309

#### © Atmel Corporation 2001.

Atmel Corporation makes no warranty for the use of its products, other than those expressly contained in the Company's standard warranty which is detailed in Atmel's Terms and Conditions located on the Company's web site. The Company assumes no responsibility for any errors which may appear in this document, reserves the right to change devices or specifications detailed herein at any time without notice, and does not make any commitment to update the information contained herein. No licenses to patents or other intellectual property of Atmel are granted by the Company in connection with the sale of Atmel products, expressly or by implication. Atmel's products are not authorized for use as critical components in life support devices or systems.

 $Atmel^{\otimes}$  is the registered trademark of Atmel. Atmel-WINCUPL<sup>TM</sup> and ProChip Designer<sup>TM</sup> are the trademarks of Atmel.

Pentium® and Pentium II® are the registered trademarks of Intel Corporation. Windows 95®, Windows 98®, Windows NT® and Windows ME® are the registered trademarks of Microsoft Corporation. Terms and product names in this document may be trademarks of others.

