

# AC Voltage Zero Cross Detection IC BM1Z002FJ Evaluation Board

User's Guide

# <High Voltage Safety Precautions>

 $\bigcirc$  Read all safety precautions before use

Please note that this document covers only the BM1Z002FJ evaluation board (BM1Z002FJ-EVK-001) and its functions. For additional information, please refer to the datasheet.

# To ensure safe operation, please carefully read all precautions before handling the evaluation board



Depending on the configuration of the board and voltages used,

# Potentially lethal voltages may be generated.

Therefore, please make sure to read and observe all safety precautions described in the red box below.

#### **Before Use**

- [1] Verify that the parts/components are not damaged or missing (i.e. due to the drops).
- [2] Check that there are no conductive foreign objects on the board.
- [3] Be careful when performing soldering on the module and/or evaluation board to ensure that solder splash does not occur.
- [4] Check that there is no condensation or water droplets on the circuit board.

### **During Use**

- [5] Be careful to not allow conductive objects to come into contact with the board.
- [6] Brief accidental contact or even bringing your hand close to the board may result in discharge and lead to severe injury or death.

Therefore, DO NOT touch the board with your bare hands or bring them too close to the board.

In addition, as mentioned above please exercise extreme caution when using conductive tools such as tweezers and screwdrivers.

- [7] If used under conditions beyond its rated voltage, it may cause defects such as short-circuit or, depending on the circumstances, explosion or other permanent damages.
- [8] Be sure to wear insulated gloves when handling is required during operation.

### After Use

- [9] The ROHM Evaluation Board contains the circuits which store the high voltage. Since it stores the charges even after the connected power circuits are cut, please discharge the electricity after using it, and please deal with it after confirming such electric discharge.
- [10] Protect against electric shocks by wearing insulated gloves when handling.

This evaluation board is intended for use only in research and development facilities and should by handled **only by qualified personnel familiar with all safety and operating procedures.** 

We recommend carrying out operation in a safe environment that includes the use of high voltage signage at all entrances, safety interlocks, and protective glasses.



**AC/DC Converter** 

# AC Voltage Zero Cross Detection IC BM1Z002FJ Evaluation Board


### BM1Z002FJ-EVK-001

# **General Description**

This evaluation board outputs a zero cross signal from 90 Vac to 264 Vac input.

The evaluation board is mounted with BM1Z002FJ which outputs high precision zero cross timing of targeted AC voltage. BM1Z002FJ will provide power less down to 1/10 of what conventional zero cross signal generator circuit consumed. The evaluation board is also mounted with power supply for the IC.





### **Performance Specification**

Not guarantee the characteristics is representative value. Ta =  $25 \degree C$ 

Parameter	Min	Тур	Мах	Units	Conditions
Input Voltage Range	90	230	264	V	
Input Frequency	47	-	63	Hz	
Output Voltage (High Level)	4.75	5.00	5.25	V	
Output Voltage (Low Level)	0.0	-	0.1	V	
Delay Time	-	0.0	-	μs	
Operating Temperature Range	-10	+25	+65	°C	

#### **Operating Procedure**

#### 1 Necessary Equipment

- (1) AC power supply (90 Vac to 264 Vac, 10 W or more)
- (2) Oscilloscope

#### 2 Connecting Equipment

- (1) Set the AC power supply to 90 Vac to 264 Vac power supply off.
- (2) Connect the output pin (ACOUT-pin, COMMON pin) to Oscilloscope (Keep isolated).
- (3) Connect the pin of the power supply (CN1) to AC power supply output with pair of wires.
- (4) AC power supply turn on.
- (5) Confirm the output waveform synchronized with the AC voltage.

Caution : To avoid the electrical shock , please keep Oscilloscope probes being isolated.




Figure 2. Diagram of How to Connect

### **Application Circuit**

This evaluation board outputs a zero cross signal.

Output a zero cross point of the AC voltage from ACOUT pins by monitoring the voltage between VH\_AC1 pins and the VH\_AC2 pins of IC1.

600V withstand monitor circuit is integrated at VH\_AC1 pin and VH\_AC2 pin to realize high reliabitity and low power consumption. ACOUT pin output 5V as high level and 0V as low level.






Figure 3. Application Circuit Edge CH1 **F** 4.00 V Auto Norm:Hi-Res 125MS/s YOKOGAWA 6.25 N VACOUT 5 V / Div





5ms/div

## BM1Z002FJ.General Description

#### Features

This IC outputs the AC voltage zero cross timing detection with high accuracy.

By eliminating the need for opto-coupler and external components required in conventional applications, it is possible to reduce the number of parts drastically and realize compact and highly reliable power supply applications. In addition, this IC can reduce standby power largely in comparison with an existing opto-coupler control.

#### **Pin Configuration**




Figure 5. Pin Configuration

#### **Key Specifications**

■ VCC Input Power Supply Voltage Range:

-0.3 V to +29.0 V

■ VH\_AC1 and VH\_AC2 Pins Operation Voltage:

	600 V (Max)
Circuit Current at Standby:	50 µA (Typ)
Circuit Current at Operation:	160 µА (Тур)

■ Operating Temperature Range: -40 °C to +105 °C


Package

SOP-J7S

W (Typ) x D (Typ) x H (Max)

4.90 mm x 6.00 mm x 1.65 mm Pitch (Typ): 1.27 mm





#### **Pin Descriptions**

No.	Pin Name	I/O	Function
1	ACOUT	0	AC voltage zero cross timing output pin
2	DSET	I	AC voltage zero cross delay time setting pin
3	GND	-	Ground pin
4	VCC	I	Power supply pin
5	N.C	-	Non connection (Do not connect to any pins.)
6	VH_AC2	I	AC voltage input 2 pin
7	VH_AC1	I	AC voltage input 1 pin

#### 1 Important Parameter

Parameter	Symbo I	Min	Тур	Мах	Units	Conditions
Input Voltage Range	V <sub>IN</sub>	90	230	264	V	
Output Voltage (High Level)	V <sub>OUTH</sub>	4.75	5.00	5.25	V	
Output Voltage (Low Level)	V <sub>OUTL</sub>	0.0	0.0	0.1	V	
Delay Time	T <sub>DELAY</sub>	-	0.0	-	μs	

Zero cross delay time is adjustable by the external (R3) between DSET pins and GND pins.

R3	Setting delay time
OPEN	0 µ s
330 kΩ	200 µ s
68 kΩ	-200 µ s
0 Ω	-480 µ s

R3 setting with this evaluation board is OPEN. Thus, the delay time works in 0  $\mu sec.$ 

#### **Measurement Data**

- 1 Input output waveform
  - R3 : OPEN




Figure 7. Input output waveform  $V_{IN} = 90$  Vac

R3 : 330 kΩ




Figure 9. Input output waveform V<sub>IN</sub> = 90 Vac R 3 :0  $\Omega$ 




Figure 11. Input output waveform  $V_{\text{IN}}\,{=}\,90$  Vac




Figure 8. Input output waveform  $V_{IN} = 264$  Vac

 $R3~:~8~k\Omega$ 




Figure 10. Input output waveform  $V_{IN} = 90$  Vac

# **Application Circuit**

(Condition)  $V_{IN} = 90$  Vac to 264 Vac




Figure 12. BM1Z002FJ-EVK-001 Application Circuit

### Parts List

Item		Specifications	Parts name	Manufacture	
CONNECTOR CN1			B02P-NV	JST	
	C1	0.1 µF, 275 V	890324023023CS	WURTH ELECTRONIK	
	C2	4.7 µF, 400 V	860021374008	WURTH ELECTRONIK	
Capacitor	C3	220 µF, 25 V	860080474010	WURTH ELECTRONIK	
Capacitor	C4	2.2 µF, 35 V	UMK212BB7225KG-T	TAIYO YUDEN	
	C7	0.1 µF, 100 V	HMK107B7104MA-T	TAIYO YUDEN	
	C8	1 μF, 50 V	UMK212B7105KG-T	TAIYO YUDEN	
Diode-Bridge	DA1	1 A, 800 V	D1UBA80	SHINDENGEN	
	D1	1 A, 1 kV	1N4007		
Diode	D2	1 A, 1 kV	1N4007		
Diode	D3	FRD, 0.8 A, 600 V	RFN1LAM6S	ROHM	
	D4	0.2 A, 600 V	RRE02VSM6S	ROHM	
Fuse	F1	1 A, 300 V	36911000000	LITTELFUSE	
	IC1		BM1Z002FJ	ROHM	
IC	IC2		BM2P129TF	ROHM	
	IC3		BD50FA1FP3	ROHM	
Coil	L1	220 µH	7447471221	WURTH ELECTRONIK	
	R1	100 Ω	MCR18EZPJ101	ROHM	
Resistor	R2	100 Ω	MCR18EZPJ101	ROHM	
	R7	100 kΩ	MCR03EZPJ104	ROHM	
	C6	33 kΩ	MCR03EZPJ333	ROHM	
Pin	TP	Black	LC-2-G		
FIII	TP	Red	LC-2-G		

(Note 1) Materials may be changed without notifying.

#### Layout

Size: 36 mm x 90 mm




Figure 13. TOP Silkscreen (Top view)




Figure 14. Bottom Layout (Top View)

# **Revision History**

Date	Rev.	Changes
30.Mar.2020	001	New Release

	Notes
	Notes
1)	The information contained herein is subject to change without notice.
2)	Before you use our Products, please contact our sales representative and verify the latest specifica- tions :
3)	Although ROHM is continuously working to improve product reliability and quality, semicon- ductors can break down and malfunction due to various factors. Therefore, in order to prevent personal injury or fire arising from failure, please take safety measures such as complying with the derating characteristics, implementing redundant and fire prevention designs, and utilizing backups and fail-safe procedures. ROHM shall have no responsibility for any damages arising out of the use of our Poducts beyond the rating specified by ROHM.
4)	Examples of application circuits, circuit constants and any other information contained herein are provided only to illustrate the standard usage and operations of the Products. The peripheral conditions must be taken into account when designing circuits for mass production.
5)	The technical information specified herein is intended only to show the typical functions of and examples of application circuits for the Products. ROHM does not grant you, explicitly or implicitly, any license to use or exercise intellectual property or other rights held by ROHM or any other parties. ROHM shall have no responsibility whatsoever for any dispute arising out of the use of such technical information.
6)	The Products specified in this document are not designed to be radiation tolerant.
7)	For use of our Products in applications requiring a high degree of reliability (as exemplified below), please contact and consult with a ROHM representative : transportation equipment (i.e. cars, ships, trains), primary communication equipment, traffic lights, fire/crime prevention, safety equipment, medical systems, servers, solar cells, and power transmission systems.
8)	Do not use our Products in applications requiring extremely high reliability, such as aerospace equipment, nuclear power control systems, and submarine repeaters.
9)	ROHM shall have no responsibility for any damages or injury arising from non-compliance with the recommended usage conditions and specifications contained herein.
10)	ROHM has used reasonable care to ensure the accuracy of the information contained in this document. However, ROHM does not warrants that such information is error-free, and ROHM shall have no responsibility for any damages arising from any inaccuracy or misprint of such information.
11)	Please use the Products in accordance with any applicable environmental laws and regulations, such as the RoHS Directive. For more details, including RoHS compatibility, please contact a ROHM sales office. ROHM shall have no responsibility for any damages or losses resulting non-compliance with any applicable laws or regulations.
12)	When providing our Products and technologies contained in this document to other countries, you must abide by the procedures and provisions stipulated in all applicable export laws and regulations, including without limitation the US Export Administration Regulations and the Foreign Exchange and Foreign Trade Act.
13)	This document, in part or in whole, may not be reprinted or reproduced without prior consent of ROHM.



Thank you for your accessing to ROHM product informations. More detail product informations and catalogs are available, please contact us.

# ROHM Customer Support System

http://www.rohm.com/contact/