# Panasonic

# **Automation Controls Catalog**







Terminal socket for PC board

Terminal socket for soldering

#### **RoHS compliant**

## **TYPES**

Product name	Part No.
Terminal socket for PC board	ST-PS
Terminal socket for soldering	ST-SS

## FEATURES

- 1. Possible to fit or remove the chassis with one touch (t = 0.6 mm to 2.2mm .024 inch to .087 inch)
- 2. Easy design of PC board pattern (2.54 mm x 4 pitch DIL terminal array)
- 3. High breakdown voltage.

# PRECAUTIONS FOR USE (SOCKET)

1. PC board mounting method PC board pattern

Contact



The terminal configuration is symmetrical on the left and right, so an arrow mark  $\hat{T}$ is stamped on the socket to prevent misinsertion. We recommend printing the same arrow mark  $\mathop{ \mbox{\scriptsize $\Omega$}}$  on the component mounting side (side opposite from pattern) of the PC board. In this case, the terminal configuration becomes the terminal nos. noted near the drilling holes.

# SPECIFICATIONS

ACCESSORIES

Item	Specifications
Breakdown voltage (Initial)	Between contact and coil: 4,000 Vrms for 1 min. (Detection current: 10 mA) Between contact and terminal: 2,000 Vrms for 1 min.
Insulation resistance (Initial)	Min. 1,000 MΩ between terminals (500V DC)
Heat resistance	150°C 302°F for 1 hr
Max. continuous current	10 A
Relay insertion life	15 times

### DIMENSIONS (mm inch)

#### Terminal socket for PC board

2. Chassis cutout

A side

77777777

side (A side).

Chassis cutting dimensions

32.5±0.1

0


2.2 mm .024 to .087 inch.

If the chassis hole is punched with a

press, set so the release R on the front

The range for chassis thickness is 0.6 to


0



can be downloaded from: http://industrial.panasonic.com/ac/e/

ST RELAYS TERMINAL SOCKETS






#### 3. Relay mounting and removal

(1) Align the directions of the relay and socket. Rela<sub>\</sub>



(2) Insert the relay all the way in, so it is securely in place.



(3) Press the part indicated by A in the B direction, and fasten by placing the hook on the relay.



(4) When removing the relay, completely release the hooks on both sides and pull the relay out.

# 2014.02 industrial.panasonic.com/ac/e/

15.0+0.2

Claw for chassis

fastening

Chassis t = 0.6 to 2.2

## The CAD data of the products with a CAD Data mark Terminal socket for soldering