


WILMAR™ Protective Relays – WOUF Series, Over/Underfrequency



Note: Dimensions in inches. Multiply values by 25.4 for dimensions in mm.

1-2-3-4-5-6

Time Delay

Standard Time Delay

A minimum, fixed inverse time delay is incorporated in all frequency relays to prevent nuisance tripping and is represented by the typical curves shown below.

Adjustable Time Delay

If additional time delay is required, a suffix "T" must be added to the part number. This allows the minimum fixed time delay to be field-adjustable up to 20 seconds


PRODUCT SPECIFICATIONS	
Part Number	WOUF Series
Nominal Voltage (±20%)	120, 230, 380 and 460 volts
Nonimal Frequencies	50, 60 and 400 Hz.
Trip Point	Screwdriver adjustable. Adjustment range in accordance with ordering information.
Operating Temperature	-40°C to +65°C
Differential	The frequency pick-up to drop-out differential is .5% max
Voltage Drift	\pm 0.05% maximum frequency error for input voltage variation of $\pm 10\%$
Time Delay	See Time versus Frequency curves
Surge Withstand Capability	In compliance with C37-90B ANSI/IEEE
Output Contacts	One set N.O., one set N.C.
Contact Ratings	5 amp resistive at 120 VAC or 28 VDC

Notes:

- 1. Remove black screws for access to the frequency and the time adjustments.
- 2. Clockwise rotation of the frequency potentiometer will raise the frequency trip point.
- 3. Clockwise rotation of the time adjustment, option "T" will increase the drop-out time delay.

Function: 81 O/U

- ANSI/IEEE C37.90-1978
- UL file No. E58048









The output contacts of frequency relays are energized when the frequency exceeds the adjustable set point. Overfrequency and underfrequency relays are available in 50, 60 and 400Hz. Combination over/underfrequency "band pass" relays are also available. These are energized at rated frequency and de-energized during overfrequency or underfrequency conditions. Frequency Differential relays are energized above the preset frequency. The pick-up and drop-out frequency settings are independently adjustable.

Operation:

The relay will energize at normal frequency; The normally closed contacts will open and the normally open contacts will close. The relay will drop-out after time delay at overfrequency or underfrequency.





Consult factory for additional models.

T = Adjustable